

### Compact Manifold Regulator

#### Series ARM10/11



#### Allows high degree of freedom in selection according to the installation conditions.

- Handle position: Top. Front. Bottom
- · Piping direction: Top ported, Bottom ported
- · One-touch fitting types: Straight, Elbow



#### Types and sizes of the One-touch fittings can be changed.



		Applic	cable tul	oing O.D	. (mm)
	Fitting type	4	6	8	10
IN side	Straight, Elbow				
OUT side	Straight, Elbow				

Also available in inch sizes

#### Reverse flow function is equipped as a standard.

Can control thrust of the actuator.

#### Four types of supply blocks (for common supply)

The mounting position of the supply block can be selected

from the right, left and both sides of the manifold.										
Supply block	With 3-way pressure relief valve	With pressure switch	With 3-way pressure relief valve + Pressure switch							

#### Mixed manifold

Common exhaust type and individual exhaust type can be mounted on the same manifold base.

(Available as Simple Specials)



#### Pressure gauge with limit indicator.

Opening and closing lens cover makes adjustment easy.

#### Compatible with units with a digital pressure switch

Individual lines can be controlled with electric signals.



ARJ AR425

to 935 ARX

AMR

ARM ARP

IR

IRV VEX

SRH

SRP SRF

**VCHR** ITV

IC

ITVX PVQ

VEF VEP

VER

VEA VY1

VBA VBAT


#### **Compact Manifold Regulator**

### **Common Supply Type**

Series ARM11A



#### How to Order



#### 1. Handle Position



#### 2. IN/OUT Piping Position

Position Symbol	IN s Bottom		OUT	side Top	IN side Top OUT s	
1	•		•		Elbow	Top
3	•	•		÷		20000
4		•	•		- 0	5 299
					Bottom	IN side fitting OUT side fitting Straight

#### 3. Regulator Block Stations


Symbol	Stations				
1	1 station				
2	2 stations				
3	3 stations				
4	4 stations				
5	5 stations				
6	6 stations				
7	7 stations				
8	8 stations				
9	9 stations				
М	10 stations				

#### 4. IN/OUT Fitting Type (Refer to the figure below.)


Metric s	ize										-	Inch siz	е									
Mounting position			IN s	side			(	TUC	side	Э	ſ	Mounting position			IN s	side			(	TUC	side	9
Fitting type	S	traig	ht	E	Elbov	W	Stra	ight	Elbo	w <sup>Note)</sup>	ŀ	Fitting type	S	traig	ht	E	Elbo	W	Stra	ight	Elbo	w No
Symbol	ø6	ø8	ø10	ø6	ø8	ø10	ø4	ø6	ø4	ø6		Symbol	ø1/4	ø5/16	ø3/8	ø1/4	ø5/16	ø3/8	ø5/32	ø1/4	05/32	ø1
07	•						•					57	•						•			
08	•							•				58	•							•		
09		•										59		•					•			
10		•						•			ı	60		•						•		
11			•				•					61			•				•			
12			•					•				62			•					•		
19				•					•			69				•					•	L
20				•								70				•						•
21					•				•			71					•				•	
22					•					•		72					•					•
23						•			•			73						•			•	
24						•				•		74						•				•
26	•								•			76	•								•	L
27	•									•	ı	77	•									•
28	_	•							•		ļ	78		•							•	L.
29	_	•	_						_	•	-	79		•	_						_	4
30			•						•		ŀ	80			•						•	L
31	_	_	•	_		_					ŀ	81	_		•	_						4
33	_	_	-	•	_	_	•	_	_		ŀ	83	_			•			•	_	_	L
34	<u> </u>	_		•				•			ŀ	84				•				•		
35	_			_	•	-	•	_			ŀ	85					•		•	_		L
36	_	_		_	•			•		_	ŀ	86	_				•	_		•	_	$\vdash$
37	_	_				-	•	_			ŀ	87						-	•			
38								•		$oxed{oxed}$	Į	88								•		

Note) When the handle and the OUT piping are located on the same side, the elbow fitting is directed to the rear side (DIN rail side). Use caution to ensure the connector is not disturbed, depending on piping direction, when choosing to attach a digital pressure switch.

Handle position: Top OUT piping position: Top



Handle position: Bottom OUT piping position: Bottom



#### **Compact Manifold Regulator** Common Supply Type Series ARM11A

#### 5. Accessories

	Pressure dis	splay Note 1, 2)	S	upply bloc	k type Note	3)	Supply blo	ock mountin	g position
Symbol	Without pressure display	With pressure display	Common supply block	Common supply block with pressure switch	3-way valve common supply block	3-way valve common supply block + Pressure switch block	L side (Left)	R side (Right)	B side (Both)
Nil	•		•				•		
Α	•			•			•		
В	•				•		•		
С	•					•	•		
D E	•		•					•	
E	•			•				•	
F	•				•			•	
G	•					•		•	
Н	•		•						•
J		•	•				•		
K		•		•			•		
L		•			•		•		
M		•				•	•		
N		•	•					•	
0		•		•				•	
Р		•			•			•	
Q		•						•	
R		•	•						•

Note 1) Pressure display means a pressure gauge or digital pressure switch is attached. When choosing to attach a digital pressure switch is chosen for attachment, be sure to enter the symbol, referring to table 8, "Digital Presure Switch Output Specifications". Otherwise, a pressure gauge will come with the regulator.

Note 2) Pressure gauges are not compatible with copper-free and fluorine-free specifications

Note 3) Pressure switches are not available with the oil-free specification.

#### 6. Semi-standard

Symbol	None	0.35 MPa setting Note 1)	Non- relieving	Oil-free					
Nil	•								
1		•							
2			•						
3				•					
4		•	•						
5		•		•					
6			•	•					
7		•	•	•					
Note 1) A pressure gauge with a full span of 0.4 MPa is attact									

Note 2) The oil-free specification is grease-free in the fluid contact area

8. Digital Presure Switch Output Specifications Note)

Symbol	Details
Nil	None
N	NPN open collector
P	PNP open collector

Note) When a digital pressure switch is attached, the "pressure display" in table 5 "Accessories" will be equipped. The electrical entry is positioned on the side opposite the handle.

#### Without pressure display



#### With pressure display



With pressure guage

With digital pressure switch

ARJ AR425 to 935

ARX

AMR ARM

ARP IR

IRV

VEX

SRH

SRP

SRF

**VCHR** 

ITV

IC

Common supply block



3-way valve

common

supply block

L side

Common supply block with pressure switch



3-way valve common supply block



Pressure switch block



PVO VEF

ITVX

VEP VER

VEA

VY1 VBA VBAT

AP100

#### 7. Unit Representation

Symbol	Description
Nil	Display unit for product name plate and pressure gauge: MPa
<b>Z</b> Note 1, 2)	Display unit for product name plate and pressure gauge: psi
ZA Note 1, 3)	Digital pressure switch: with unit switching (MPa is initially set.)

Note 1) This option is available for use outside Japan only. (The SI unit has to be used in Japan.) Additionally, the pressure switch offers dual unit presentation in MPa and psi.

Note 2) The digital pressure switch is equipped with unit switching and initially set to psi

Note 3) This option is available with the digital pressure switch

#### Symbol



Note) A standard model is equipped with a backflow function. Main valve opens when the inlet pressure is released, and then the outlet pressure backflows into the inlet side

#### **Specifications**

Manifold (Regulator block, Cor	nmon supp	ly block, 3-way valve common supply block)			
Regulator construction		Direct acting			
Working principal		Diaphragm regulator			
Relief mechanism	Standard	Relief type			
neller mechanism	Optional	Non-relieving type			
Backflow function Note 1)		Within (Unbalance type)			
IN side tubing O.D.		ø6, ø8, ø10, ø1/4, ø5/16, ø3/8			
OUT side tubing O.D.		ø4, ø6, ø5/32, ø1/4			
Proof pressure		1.5 MPa			
Maximum operating pressure		1.0 MPa			
	Standard	0.05 to 0.7 MPa			
Set pressure range Optional		0.05 to 0.35 MPa (Low pressure type)			
Fluid		Air			
Ambient and operating fluid tempe	erature Note 2)	5 to 60°C			

Refer to pages 676 and 678 for the digital pressure switch and pressure switch specifications.


Note 1) 0.1 MPa or greater set pressure is required when used in the reverse flow.


Note 2) 5 to 50°C when the digital pressure switch will be used.





#### Series ARM11A


#### Flow Characteristics (Representative Values)

















#### **Pressure Characteristics (Representative Values)**





### Compact Manifold Regulator Common Supply Type Series ARM11A

#### Construction



**Component Parts** 

••••	ipononii i arto	
No.	Description	Material
1	Body for regulator block	PBT
2	Bonnet	PBT
3	Handle	POM
4	Valve seat	POM
5	Adjusting screw assembly	Reinforced stee
6	Adjustment spring	Steel wire
7	Regulator clip	Stainless stee
8	Manifold block	PBT
9	Blanking plate assembly	_
10	Square nut	Steel
11	Common exhaust bushing	POM
	No. 1 2 3 4 5 6 7 8 9	1 Body for regulator block 2 Bonnet 3 Handle 4 Valve seat 5 Adjusting screw assembly 6 Adjustment spring 7 Regulator clip 8 Manifold block 9 Blanking plate assembly 10 Square nut

**Replacement Parts** 

No.	Description	Material	Part no.	Note
A Diaphragm		Weatherproof	136126A	Relieving type
А	assembly	NBR, POM	136126-1A	Non-relieving type
В	Valve	HNBR, Aluminum alloy	136127-30#1	
С	Valve spring	Stainless steel	136131	
D	Gasket	HNBR	136137-30	
Е	O-ring	NBR	136146	Standard model
-	O-ring	HNBR	136146-30	Oil-free specification
F	O winner	NBR	136147	Standard model
г	O-ring	HNBR	136147-30	Oil-free specification
		NBR	136148	Standard model
G	O-ring	HNBR	136148-30	Oil-free specification
G	O-ring	NBR	KA01731	Standard model for digital pressure switch
		HNBR	KA01613	Oil-free spec. for digital pressure switch
н	O-ring	NBR	136149	Standard model
п	O-ring	HNBR	136149-30	Oil-free specification
J	Fitting assembly	_	Refer to page 679.	
K	Port plug	PBT/HNBR	Refer to page 680.	

ARJ AR425 to 935

ARX AMR

ARM

ARP IR

IRV

VEX SRH

SRP

SRF VCHR

ITV IC

ITVX

PVQ VEF VEP

VER

VEA

VY1 VBA VBAT


#### Series ARM11A


#### **Dimensions**

#### **ARM11AA1-**□12

Handle position: Top / Common supply block

For One-touch fittings part and manifold option dimensions, refer to pages 673 to 680.






Stations	DIN rail part no. (for L and R sides)	L2 dimension
1	AXT100-DR-9	123
2	AXT100-DR-11	148
3	AXT100-DR-13	173
4	AXT100-DR-16	210.5
5	AXT100-DR-18	235.5
6	AXT100-DR-20	260.5
7	AXT100-DR-22	285.5
8	AXT100-DR-25	323
9	AXT100-DR-27	348
М	AXT100-DR-29	373

#### **ARM11AA1-**□12-A

Handle position: Top / Common supply block with pressure switch





57		<b></b>		33.5
1-1			<u>ज्या</u>	<b>-</b> + + +

Stations	DIN rail part no. (for L and R sides)	L2 dimension
1	AXT100-DR-9	123
2	AXT100-DR-11	148
3	AXT100-DR-13	173
4	AXT100-DR-16	210.5
5	AXT100-DR-18	235.5
6	AXT100-DR-20	260.5
7	AXT100-DR-22	285.5
8	AXT100-DR-25	323
9	AXT100-DR-27	348
М	AXT100-DR-29	373


### Compact Manifold Regulator Common Supply Type Series ARM11A

#### **Dimensions**

#### ARM11AA1-□12-B

Handle position: Top / 3-way valve common supply block

For One-touch fittings part and manifold option dimensions, refer to pages 673 to 680.





51	33.5		<b>⊕</b>	<b>@</b>	<b>⊕</b>	<b>@</b>	_	41	53

Stations	DIN rail part no. (for L and R sides)	L2 dimension
1	AXT100-DR-9	123
2	AXT100-DR-11	148
3	AXT100-DR-13	173
4	AXT100-DR-16	210.5
5	AXT100-DR-18	235.5
6	AXT100-DR-20	260.5
7	AXT100-DR-22	285.5
8	AXT100-DR-25	323
9	AXT100-DR-27	348
М	AXT100-DR-29	373

#### **ARM11AA1-**□12-C

Handle position: Top / 3-way valve common supply block + Pressure switch block





DIN rail part no.	L2 dimension
AXT100-DR-11	148
AXT100-DR-13	173
AXT100-DR-15	198
AXT100-DR-17	223
AXT100-DR-19	248
AXT100-DR-22	285.5
AXT100-DR-24	310.5
AXT100-DR-26	335.5
AXT100-DR-28	360.5
AXT100-DR-31	398
	AXT100-DR-11  AXT100-DR-13  AXT100-DR-15  AXT100-DR-17  AXT100-DR-19  AXT100-DR-22  AXT100-DR-24  AXT100-DR-26  AXT100-DR-28

ARJ

AR425 to 935

ARX

ARM

ARP

IR

IRV

VEX SRH

SRP

SRF VCHR

ITV

IC

ITVX

PVQ

VEF VEP

VER

VEA VY1

VBA VBAT


#### Series ARM11A


#### **Dimensions**

**ARM11AB1-**□12

Handle position: Front / Common supply block

For One-touch fittings part and manifold option dimensions, refer to pages 673 to 680.







Stations	DIN rail part no.	L2 dimension
1	AXT100-DR-9	123
2	AXT100-DR-11	148
3	AXT100-DR-13	173
4	AXT100-DR-16	210.5
5	AXT100-DR-18	235.5
6	AXT100-DR-20	260.5
7	AXT100-DR-22	285.5
8	AXT100-DR-25	323
9	AXT100-DR-27	348
М	AXT100-DR-29	373

#### ARM11AB1-□12-A

Handle position: Front / Common supply block with pressure switch





118		33.5

Stations	DIN fall part no.	L2 uillielision
1	AXT100-DR-9	123
2	AXT100-DR-11	148
3	AXT100-DR-13	173
4	AXT100-DR-16	210.5
5	AXT100-DR-18	235.5
6	AXT100-DR-20	260.5
7	AXT100-DR-22	285.5
8	AXT100-DR-25	323
9	AXT100-DR-27	348
M	AXT100-DR-29	373


### Compact Manifold Regulator Common Supply Type Series ARM11A


#### **Dimensions**

ARM11AB1-□12-B

Handle position: Front / 3-way valve common supply block

For One-touch fittings part and manifold option dimensions, refer to pages 673 to 680.







Stations	DIN rail part no.	L2 dimension
1	AXT100-DR-9	123
2	AXT100-DR-11	148
3	AXT100-DR-13	173
4	AXT100-DR-16	210.5
5	AXT100-DR-18	235.5
6	AXT100-DR-20	260.5
7	AXT100-DR-22	285.5
8	AXT100-DR-25	323
9	AXT100-DR-27	348
М	AXT100-DR-29	373

52.5

#### ARM11AB1-□12-C

Handle position: Front / 3-way valve common supply block + Pressure switch block





Stations	DIN rail part no.	L2 dimension
1	AXT100-DR-11	148
2	AXT100-DR-13	173
3	AXT100-DR-15	198
4	AXT100-DR-17	223
5	AXT100-DR-19	248
6	AXT100-DR-22	285.5
7	AXT100-DR-24	310.5
8	AXT100-DR-26	335.5
9	AXT100-DR-28	360.5
M	AXT100-DR-31	398

ARJ

AR425 to 935

ARX

ARM

ARP

IR

IRV

VEX

SRH

SRP SRF

VCHR

ITV

IC

ITVX

PVQ

VEF VEP

VEA

VY1

VBA VBAT


#### Series ARM11A


#### **Dimensions**

#### ARM11AC2-□12

Handle position: Bottom / Common supply block

For One-touch fittings part and manifold option dimensions, refer to pages 673 to 680.







53	1	
20	33.5	

Stations	DIN rail part no.	L2 dimension
1	AXT100-DR-9	123
2	AXT100-DR-11	148
3	AXT100-DR-13	173
4	AXT100-DR-16	210.5
5	AXT100-DR-18	235.5
6	AXT100-DR-20	260.5
7	AXT100-DR-22	285.5
8	AXT100-DR-25	323
9	AXT100-DR-27	348
М	AXT100-DR-29	373

#### ARM11AC2-□12-A

Handle position: Bottom / Common supply block with pressure switch





Stations	DIN fall part no.	L2 uillielision
1	AXT100-DR-9	123
2	AXT100-DR-11	148
3	AXT100-DR-13	173
4	AXT100-DR-16	210.5
5	AXT100-DR-18	235.5
6	AXT100-DR-20	260.5
7	AXT100-DR-22	285.5
8	AXT100-DR-25	323
9	AXT100-DR-27	348
M	AXT100-DR-29	373


### Compact Manifold Regulator Common Supply Type Series ARM11A

#### **Dimensions**

ARM11AC2-□12-B

Handle position: Bottom / 3-way valve common supply block

For One-touch fittings part and manifold option dimensions, refer to pages 673 to 680.





	33.5
--	------

Stations	DIN rail part no.	L2 dimension
1	AXT100-DR-9	123
2	AXT100-DR-11	148
3	AXT100-DR-13	173
4	AXT100-DR-16	210.5
5	AXT100-DR-18	235.5
6	AXT100-DR-20	260.5
7	AXT100-DR-22	285.5
8	AXT100-DR-25	323
9	AXT100-DR-27	348
M	AXT100-DR-29	373

ARM11AC2-□12-C

Handle position: Bottom / 3-way valve common supply block + Pressure switch block





			33.5
--	--	--	------

Stations	DIN rail part no.	L <sub>2</sub> dimension
1	AXT100-DR-11	148
2	AXT100-DR-13	173
3	AXT100-DR-15	198
4	AXT100-DR-17	223
5	AXT100-DR-19	248
6	AXT100-DR-22	285.5
7	AXT100-DR-24	310.5
8	AXT100-DR-26	335.5
9	AXT100-DR-28	360.5
М	AXT100-DR-31	398

ARJ

AR425 to 935

ARX

ARM

ARP

IR IRV

VEX

SRH

SRF

VCHR

ITV

IC

PVQ

VEF VEP

VER

VEA VY1


VBA VBAT

#### **Compact Manifold Regulator**

### **Individual Supply Type**

Series ARM11B

#### **How to Order**






#### 1. Handle Position

Symbol A	Position Top	Top Front Bottom
В	Front	
С	Bottom	

#### 2. IN/OUT Piping Position

Position			OUT side			
Symbol	Bottom	Top	Bottom	Тор		
1	•		•			
2		•		•		
3	•			•		
4		•	•			



#### 3. Regulator Block Stations

Symbol	Stations
1	1 station
2	2 stations
3	3 stations
4	4 stations
5	5 stations
6	6 stations
7	7 stations
8	8 stations
9	9 stations
M	10 stations

#### 4. IN/OUT Fitting Type (Refer to the figure below.)

Metric s	ize								Inch siz	е							
Mounting position		IN:	side			OUT	side	,	Mounting position		IN:	side			OUT	side	
Fitting type	Stra	ight	Elbov	W Note)	Stra	ight	Elbov	N Note)	Fitting type			Elbov					N Note)
Symbol	ø4	ø6	ø4	ø6	ø4	ø6	ø4	ø6	Symbol	ø5/32	ø1/4	ø5/32	ø1/4	ø5/32	ø 1/4	ø5/32	ø1/4
06	•				•				56	•				•			
07		•			•				57		•			•			
08		•				•			58		•				•		
18			•				•		68			•				•	
19				•			•		69				•			•	
20				•				•	70				•				•
25	•						•		75	•						•	
26		•					•		76		•					•	
27		•						•	77		•						•
32			•		•				82			•		•			
33				•	•				83				•	•			
34				•		•			84				•		•		

Note) When the handle and the OUT piping are located on the same side, the elbow fitting is directed to the rear side (DIN rail side). Use caution to ensure the connector is not disturbed, depending on piping direction, when choosing to attach a digital pressure switch.

Handle position: Top
OUT piping position: Top



Rear side (DIN rail side) OUT piping position: Bottom



Handle position: Bottom

Rear side (DIN rail side)

#### 5. Accessory (Pressure Display)

Symbol	Accessory
Nil	Without pressure display
A Note 1, 2)	With pressure display

Note 1) Pressure display means a pressure gauge or digital pressure switch is attached.

When choosing to attach a digital pressure switch is chosen for attachment, be sure to enter the symbol, referring to table 8, "Digital Pressure Switch Output Specifications". Otherwise, a pressure gauge will come with the regulator.

Note 2) Pressure gauges are not compatible with copper-free and fluorine-free specifications.

#### Without pressure display







With With digital pressure guage switch

With

pressure display

#### 6. Semi-standard

Symbol	None	0.35 MPa setting Note 1)	Non- relieving	Note 2) Oil-free
Nil	•			
1		•		
2			•	
3				•
4		•	•	
5		•		•
6			•	•
7		•	•	•
				-

Note 1) A pressure gauge with a full span of 0.4 MPa is attached.

Note 2) The oil-free specification is grease-free in the fluid contact area.

#### 7. Unit Representation

Symbol	Description
Nil	Display unit for product name plate and pressure gauge: MPa
<b>Z</b> Note 1, 2)	Display unit for product name plate and pressure gauge: psi
<b>ZA</b> Note 1, 3)	Digital pressure switch: with unit switching (MPa is initially set.)

Note 1) This option is available for use outside Japan only. (The SI unit has to be used in Japan.)

Note 2) The digital pressure switch is equipped with unit switching and initially set to psi.

Note 3) This option is available with the digital pressure switch.

#### 8. Digital Presure Switch Output Specifications Note)

Symbol	Details
Nil	None
N	NPN open collector
Р	PNP open collector

Note) When a digital pressure switch is attached, the "pressure display" in table 5 "Accessory" will be equipped.

The electrical entry is positioned on the side opposite the handle.

#### **Specifications**

Regulator construction		Direct acting	
Working principal		Diaphragm regulator	
Relief mechanism	Standard	Relief type	
neller mechanism	Optional	Non-relieving type	
Backflow function Note 1)		Within (Unbalance type)	
IN side tubing O.D.		ø4, ø6, ø5/32, ø1/4	
OUT side tubing O.D.		ø4, ø6, ø5/32, ø1/4	
Proof pressure		1.5 MPa	
Maximum operating pressure		1.0 MPa	
	Standard	0.05 to 0.7 MPa	
Set pressure range	Optional	0.05 to 0.35 MPa (Low pressure type)	
Fluid		Air	
Ambient and operating fluid temp	erature Note 2)	5 to 60°C	
		ti d	

Note 1) 0.1 MPa or greater set pressure is required when used in the reverse flow. Note 2) 5 to 50°C when the digital pressure switch will be used.

Refer to page 676 for the digital pressure switch specifications.

# Symbol IN 1 2 OUT

Note) A standard model is equipped with a backflow function. Main valve opens when the inlet pressure is released, and then the outlet pressure backflows into the inlet side.

#### **⚠** Specific Product Precautions

Be sure to read before handling.

Refer to front matter 43 for Safety Instructions and pages 365 to 369 for Pre- I cautions on every series.

#### Maintenance

#### **⚠** Warning

1. Make sure to perform a periodic inspection of the pressure gauge when the compact manifold regulator is installed between a solenoid valve and an actuator. Sudden pressure changes could happen and the durability of the product could be reduced. Using an electronic style pressure gauge is recommended, depending on the situation.



ARJ AR425 to 935

ARX

AMR Arm

ARP

IR

IRV VEX

SRH

SRP

VCHR ITV

IC

ITVX PVO

VEF VEP


VER

VEA VY1

VBA VBAT

#### Series ARM11B

#### Construction




#### **Component Parts**


No.	Description	Material
1	Body for regulator block	PBT
2	Bonnet	PBT
3	Handle	POM
4	Valve seat	POM
5	Adjusting screw assembly	Reinforced steel
6	Adjustment spring	Steel wire
7	Regulator clip	Stainless steel
8	Manifold block	PBT
9	Blanking plate assembly	_
10	Square nut	Steel
11	Individual supply bushing	POM


#### Replacement Parts


No.	Description	Material	Part no.	Note
Α	Diaphragm	Weatherproof	136126A	Relieving type
^	assembly	NBR, POM	136126-1A	Non-relieving type
В	Valve	HNBR, Aluminum alloy	136127-30#1	
С	Valve spring	Stainless steel	136131	
D	Gasket	HNBR	136137-30	
Е	O-ring	NBR	136146	Standard model
	O-ring	HNBR	136146-30	Oil-free specification
F	O-ring	NBR	136147	Standard model
	O-ring	HNBR	136147-30	Oil-free specification
		NBR	136148	Standard model
G	O-ring	HNBR	136148-30	Oil-free specification
u	O-ring	NBR	KA01731	Standard model for digital pressure switch
		HNBR	KA01613	Oil-free spec. for digital pressure switch
н	O-ring	NBR	136149	Standard model
	O-ring	HNBR	136149-30	Oil-free specification
J	Fitting assembly	_	Refer to page 679.	
K	Port plug	PBT/HNBR	Refer to page 680.	


#### Flow Characteristics (Representative Values)
















#### **Pressure Characteristics (Representative Values)**





ARJ AR425 to 935

AMR ARM

ARP IR

IRV

VEX

SRH

SRF

ITV IC

ITVX PVO

VEF VEP

VEA

VY1


VBAT AP100

**SMC** 

#### Series ARM11B

#### **Dimensions**


#### ARM11BA1-□08



Stations	DIN rail part no.	L2 dimension
1	AXT100-DR-8	110.5
2	AXT100-DR-10	135.5
3	AXT100-DR-12	160.5
4	AXT100-DR-14	185.5
5	AXT100-DR-16	210.5
6	AXT100-DR-19	248
7	AXT100-DR-21	273
8	AXT100-DR-23	298
9	AXT100-DR-25	323
M	AXT100-DR-28	360.5

#### ARM11BB1-□08






Stations	DIN rail part no.	L2 dimension
1	AXT100-DR-8	110.5
2	AXT100-DR-10	135.5
3	AXT100-DR-12	160.5
4	AXT100-DR-14	185.5
5	AXT100-DR-16	210.5
6	AXT100-DR-19	248
7	AXT100-DR-21	273
8	AXT100-DR-23	298
9	AXT100-DR-25	323
М	AXT100-DR-28	360.5

52.5

#### ARM11BC2-□08




+ =	J 🔘	
33.5		9


Stations	DIN rail part no.	L2 dimension
1	AXT100-DR-8	110.5
2	AXT100-DR-10	135.5
3	AXT100-DR-12	160.5
4	AXT100-DR-14	185.5
5	AXT100-DR-16	210.5
6	AXT100-DR-19	248
7	AXT100-DR-21	273
8	AXT100-DR-23	298
9	AXT100-DR-25	323
М	AXT100-DR-28	360.5

# Compact Manifold Regulator Options

#### **Common Supply Type**



#### **Individual Supply Type**



ARJ

AR425 to 935

ARX

AMR ARM

ARP

IR

IRV

VEX

SRH SRP


SRF VCHR ITV IC

#### Series ARM11A/B

#### **Regulator Block**



#### 1. Handle Position



#### 2. OUT Piping Position 3. OUT Fitting Type

### Symbol Position 1 Bottom

2 Top

٥.	001	1 111111	ıy	ı ype
М	etric	size		

Fitting type	Straight		Elb	ow
Symbol	ø4 ø6		ø4	ø6
04	•			
05		•		
16			•	
17				•

#### Inch size

Straight		Elbow	
ø5/32 ø1/4		ø5/32	ø1/4
•			
	•		
		•	
			•

#### 4. Accessory (Pressure Display)

Symbol	Accessory
Nil	Without pressure display
A Note 1, 2)	With pressure display

Note 1) Pressure display means a pressure gauge or digital pressure switch is attached. When choosing to attach a digital pressure switch is chosen for attachment, be sure to enter the symbol, referring to table 7, "Digital Presure Switch Output Specifications". Otherwise, a pressure gauge will come with the regulator.

Note 2) Pressure gauges are not compatible with copper-free and fluorine-free specifications.

#### 5. Semi-standard

Symbol	None	0.35 MPa setting Note 1)	Non- relieving	Oil-free
Nil	•			
1		•		
2			•	
3				•
4		•	•	
5		•		•
6			•	•
7		•	•	•

Note 1) A pressure gauge with a full span of 0.4 MPa is attached. Note 2) The oil-free specification is grease-free in the fluid contact area.

#### 6. Unit Representation

Symbol	Description
Nil	Display unit for product name plate and pressure gauge: MPa
<b>Z</b> Note 1, 2)	Display unit for product name plate and pressure gauge: psi
<b>ZA</b> Note 1, 3)	Digital pressure switch: with unit switching (MPa is initially set.)

Note 1) This option is available for use outside Japan only. (The SI unit has to be used in Japan.) Additionally, the pressure switch offers dual unit presentation in MPa and psi.

Note 2) The digital pressure switch is equipped with unit switching and initially set to psi.

Note 3) This option is available with the digital pressure switch.

#### 7. Digital Presure Switch Output Specifications Note)

Symbol	Details			
Nil	None			
N NPN open collector				
Р	PNP open collector			


Note) When a digital pressure switch is attached, the "pressure display" in table 4 "Accessory" will be equipped.

The electrical entry is positioned on the side opposite the handle.

#### **Regulator Block**

### Individual Supply Type ARM11B A 1 - R 06 - A Z - N

#### 1. Handle Position



#### 2. IN/OUT Piping Position

Position	IN s	side	OUT side				
Symbol	Bottom	Тор	Bottom	Тор			
1	•		•				
2		•		•			
3	•			•			
4		•	•				

#### 3. IN/OUT Fitting Type

Metric s	ize								Inch siz	e							
Mounting position		IN side				OUT side			Mounting position		IN s	side			OUT	side	
Fitting type	Straight		Elbow		Stra	Straight Elbow		Fitting type	Stra	ight	Elb	ow	Stra	ight	Elb	ow	
Symbol	ø4	ø6	ø4	ø6	ø4	ø6	ø4	ø6	Symbol	ø5/32	ø1/4	ø5/32	ø1/4	ø5/32	ø1/4	ø5/32	ø1/4
06	•				•				56	•				•			
07		•			•				57		•			•			
08		•				•			58		•				•		
18			•				•		68			•				•	
19				•			•		69				•			•	
20				•				•	70				•				•
25	•						•		75	•						•	
26		•					•		76		•					•	
27		•						•	77		•						•
32			•		•				82			•		•			
33				•	•				83				•	•			
34				•		•			84				•		•		

#### 4. Accessory (Pressure Display)

Symbol	Accessory
Nil	Without pressure display
A Note 1, 2)	With pressure display

Note 1) Pressure display means a pressure gauge or digital pressure switch is attached.

When choosing to attach a digital pressure switch is chosen for attachment, be sure to enter the symbol, referring to table 7, "Digital Presure Switch Output Specifications".

Otherwise, a pressure gauge will come with the regulator.

Note 2) Pressure gauges are not compatible with copper-free and fluorine-free specifications.

#### 5. Semi-standard

Symbol	None	0.35 MPa setting Note 1)	Non- relieving	Oil-free
Nil	•			
1		•		
2			•	
3				•
4		•	•	
5		•		•
6			•	•
7		•	•	•

Note 1) A pressure gauge with a full span of 0.4 MPa is attached. Note 2) The oil-free specification is grease-free in the fluid contact area.

#### 6. Unit Representation

Symbol	Description
Nil	Display unit for product name plate and pressure gauge: MPa
<b>Z</b> Note 1, 2)	Display unit for product name plate and pressure gauge: psi
7 ▲ Note 1, 3)	Digital pressure switch: with unit switching (MPa is initially set.)

Note 1) This option is available for use outside Japan only. (The SI unit has to be used in Japan.) Additionally, the pressure switch offers dual unit presentation in MPa and psi.

Note 2) The digital pressure switch is equipped with unit switching and initially set to psi.

Note 3) This option is available with the digital pressure switch.

#### 7. Digital Presure Switch Output Specifications Note)

Symbol	Details
Nil	None
N	NPN open collector
Р	PNP open collector

Note) When a digital pressure switch is attached, the "pressure display" in table 4 "Accessory" will be equipped.
The electrical entry is positioned on the side opposite the handle.

ARJ AR425

to 935

AMR

ARP

IR IRV

VEX

SRH

SRP

VCHR

ITV IC

ITVX

PVQ

VEP VER

VEA

VY1

VBA VBAT


#### Series ARM11A/B

#### **Digital Pressure Switch**



Specificati	ions				
Rated press	sure range	0 to 1 MPa			
Display/Set	pressure range	-0.1 to 1 MPa			
Withstand p	pressure	1.5 MPa			
Display/Min	imum setting unit	0.01 MPa			
Applicable 1	fluid	Air, Non-corrosive gas, Non-flammable gas			
Power supp	oly voltage	12 to 24 VDC ± 10%, Ripple (p-p) 10% or less (With power supply polarity protection)			
Current cor	sumption	55 mA or less (at no load)			
Switch outp	out	NPN or PNP open collector output: 1 output			
	Max. load current	80 mA			
	Max. applied voltage	30 V (With NPN output)			
	Residual voltage	1 V or less (With load current of 80 mA)			
	Response time	1 s (0.25, 0.5, 2, 3 selections)			
Short circui	it protection	Yes			
Repeatabili	ty	±1% F.S.			
Hysteresis	Hysteresis mode	Adjustable (can be set from 0)			
Tiysteresis	Window comparator mode	Adjustable (can be set nom o)			
Diamless		3-digit, 7-segment indicator, 2-color display (Red/Green)			
Display		A switch can be operated simultaneously.			
Display acc	uracy	$\pm 2\%$ F.S. $\pm 1$ digit (at 25°C $\pm 3$ °C ambient temperature)			
Indicator light		Illuminates when output is ON. (Green)			
Environmental Enclosure		IP40			
resistance Operating temperature range		- 5 to 50°C (No freezing or condensation)			
Lead wire w	vith connector Note) (Option: L)	ø3.4 3-wire 25 AWG 2 m With connector cover			
Weight	<u> </u>	Approx. 14g (body only)/Approx. 38g (including lead wire with connector)			
Standards		CE, UL, CSA, RoHS			


Note) Refer to the Operation Manual in SMC's website (http://www.smcworld.com) for wiring.



**ØSMC** 

#### Compact Manifold Regulator Series ARM11A/B

#### **Common Supply Block**



#### 1. IN Piping Position

Symbol	Position
1	Bottom
2	Тор

#### 3. IN Fitting Type

Metric size				Inch size										
Fitting type	S	traig	ht	ı	Elbov	v		Fitting type	S	traig	ht	E	Elbov	/
Symbol	ø6	ø8	ø10	ø6	ø8	ø10		Symbol	Ø1/4	ø5/16	ø3/8	Ø1/4	ø5/16	ø3/8
01	•							51	•					
02		•						52		•				
03			•					53			•			
13				•				63				•		
14					•			64					•	
15						•		65						•

#### 4. Option

Symbol	Description
Nil	None
3	Oil-free

Note) The oil-free type has non-greased fluid contact areas.

#### 5. Accessory

Symbol	Description
Nil	Pressure switch lead wire length: 0.5 m
Α	Pressure switch lead wire length: 3.0 m

Note) Leave the field blank for types without pressure switch.

#### 6. Unit Representation

Symbol	Description
Nil	Display unit for product name plate: MPa
Z Note)	Display unit for product name plate: psi

Note) This option is available for use outside Japan only. (The SI unit has to be used in Japan.) Additionally, the pressure switch offers dual unit presentation in MPa and psi.

#### 2. Common Supply Block Type


Common supply

block (S)

Symbol	Description
S	Common supply block
P	Common supply block with pressure switch
V	3-way valve common supply block
W	3-way valve common supply block + Pressure switch block

Note) The oil-free specification is not available for P and W types of common supply blocks (types with pressure switch).

# pressure switch (P)



677

ARJ AR425

ARX AMR

ARM

ARP

IR IRV VEX SRH SRP

SRF VCHR

VBAT AP100

Common supply

block with

#### Series ARM11A/B

#### **Pressure Switch Block**




#### 1. Accessory

Symbol	Description					
Nil	Pressure switch lead wire length: 0.5 m					
Α	Pressure switch lead wire length: 3.0 m					

#### 2. Unit Representation

Symbol	Description
Nil	Display unit for product name plate: MPa
Z Note)	Display unit for product name plate: psi

Note) This option is available for use outside Japan only. (The SI unit has to be used in Japan.) Additionally, the pressure switch offers dual unit presentation in MPa and psi.




#### **Specifications**


Pressure switch (Common supply block with pressure switch, 3-way valve common supply block plus pressure switch block)

Contact type		Reed type	
Contact construction	Reed switch type		
Contact component		1a	
Reed switch action	Pisto	on type (built-in mag	gnet)
Wiring specification		Grommet type	
Wiring length	0.	5 m (standard mode	el)
Proof pressure	1.0 MPa		
Maximum operating pressure	0.7 MPa		
Set pressure range	0.1 to 0.6 MPa		
Hysteresis	0.08 MPa or less		
Repeatability	±0.05 MPa		
Maximum contact capacity	AC 2 VA, DC 2 W		
Operating voltage AC, DC	24 V or less 48 V 100 V		100 V
Max. operating current and range	50 mA	40 mA	20 mA
Impact resistance	30 G		
Environmental resistance Enclosure	IP40		

#### **Set Pressure Range**



#### **Electric Circuit**



#### Compact Manifold Regulator Series ARM11A/B

#### **DIN Rail**


#### . When only DIN rail is required:

DIN rail part no.

#### AXT100-DR-7

#### L dimension

Select L dimension from the table below and enter an applicable symbol.





L Dimension

L

398

L=12.5 x n+10.5 Symbol 2 3 4 8 9 10 23 35.5 48 60.5 73 85.5 98 110.5 123 135.5 Symbol 17 18 19 20 11 12 13 14 15 16 148 160.5 173 185.5 198 210.5 223 235.5 248 260.5 21 22 23 24 25 26 27 28 29 30 Symbol 273 285.5 298 310.5 323 335.5 348 360.5 373 385.5 Symbol 31 32 33 34 35 36 37 38 39 40

448

460.5

#### **One-touch Fittings for Regulator Block**

410.5

423


435.5


#### One-touch Fittings for Common Supply Block


485.5

498

473







Straight type		Elbow type		
<del>=</del>	× ×	Y	6.5	×

Fitting size	х
ø4, ø5/32	3
ø6	3
ø1/4	7

Fitting size	Х	Υ
ø4, ø5/32	11.5	19
ø6	11.5	19.5
ø1/4	11.5	22

<u> </u>	
<b>*</b>	5

Fitting size	Х
ø6	5
ø8, ø5/16	5
ø10, ø3/8	5.5
ø1/4	5

×	12.5	Y	,

Fitting size	Х	Υ
ø6	19	20
ø8, ø5/16	20	23
ø10, ø3/8	22	26
ø1/4	19	20.5

ARJ

AR425 to 935

ARX AMR

ARM ARP

IR

IRV

VEX

SRH

SRP

SRF **VCHR** 

ITV

IC

ITVX

PVQ

VEF

VEP

VER

VEA


VY1

VBA VBAT AP100

510.5

#### Series ARM11A/B

#### **End Block**





#### **Pressure Gauge**


Part no.	Pressure gauge indication range	Indication unit
GC3-4A-X2101	0 to 0.4 MPa	MPa
GC3-10A-X2101	0 to 1.0 MPa	IVIFA
GC3-P4A-X2101	0 to 60 psi	psi
GC3-P10A-X2101	0 to 150 psi	psi

#### Specifications


орсонновного	opeomodione						
Display accuracy	±3%F.S. (Full Span)						
Calibration angle	230°						
Limit indicator	With limit indicator						








#### **Port Plug**



#### **Bushing**


Part no.	Description
136144-S	Common supply bushing
136144-K	Individual supply bushing
130144-N	individual supply bushing



### Regulator Single Unit Type

Series ARM10

#### **How to Order**




#### 1. IN/OUT Fitting Type

lounting position		IN:	side		OUT side			
Fitting type	Stra	ight	Elbov	N Note)	Stra	ight	Elbow Note	
Symbol	ø4	ø6	ø4	ø4 ø6		ø4 ø6		ø6
06	•				•			
07		•			•			
08		•				•		
18			•				•	
19				•			•	
20			•				•	
25	•						•	
26		•					•	
27		•						•
32			•		•			
33				•	•			
34				•		•		

Bracket

Note 1) In case of a type with bracket, the panel nut is included. Note 2) Pressure display means a pressure gauge or digital pressure.

Mounting position		IN s	side		OUT side				
Fitting type	Stra	ight	Elbov	N Note)	Stra	ight	Elbov	N Note)	
Symbol	ø5/32	ø1/4	ø5/32 ø1/4		ø5/32 ø1/4		ø5/32 Ø 1.		
56	•				•				
57		•			•				
58		•				•			
68			•				•		
69				•			•		
70				•				•	
75	•						•		
76		•					•		
77		•						•	
82			•		•				
83				•	•				
84				•		•			



Digital pressure switch

Elbow

SRH SRP

ARJ AR425

to 935 ARX

AMR

ARM

ARP IR IRV VEX

SRF VCHR

ITV

IC

ITVX PVQ

VER

VEA VY1

VBA VBAT

AP100

3. Semi-standard

2. Accessories

None

Symbol

Nil В G

P

BG

GP

Nil N

Symbol	None	0.35 MPa setting Note 1)	Non- relieving	Oil-free
Nil	•			
1		•		
2	3		•	
3				
4		•	•	
5		•		•
6			•	•
7		•	•	•

#### 4. Unit Representation

When choosing to attach a digital pressure switch is chosen for attachment, be sure to enter the symbol, referring to table 5, "Digital Presure Switch Output Specifications". Otherwise, a pressure gauge will come with the regulator.

Panel nut

( • i

Additionally, pressure gauges are not compatible with copper-free and fluorine-free specifications

Pressure gauge

Symbol	Description
Nil	Display unit for product name plate and pressure gauge: MPa
<b>Z</b> Note 1, 2)	Display unit for product name plate and pressure gauge: psi
<b>ZA</b> Note 1, 3)	Digital pressure switch: with unit switching (MPa is initially set.)

Panel nut

Pressure

gauge

Note 1) This option is available for use outside Japan only. (The SI unit has to be used in Japan.) Additionally, the pressure switch offers dual unit presentation in MPa and psi.

Note 2) The digital pressure switch is equipped with unit switching and initially set to

Note 3) This option is available with the digital pressure switch.

#### Note 2) The oil-free specification is grease-free in the fluid contact area

5. Digital F	resure Switt	n Output Specifications	
Symbol	Details		

PNP open collector Note) When a digital pressure switch is attached, the "pressure display" in table 2 "Accessories" will be equipped.
The electrical entry is positioned on the side opposite the


NPN open collector




#### How to Order



### Front Handle Type ARM10F







#### 2. IN/OUT Fitting Type

Metric size

Mounting position		IN:	side					
Fitting type	ting type Straight Elbow Note)		Straight		Elbow Note			
Symbol	ø4	ø6	ø4	ø6	ø4	ø6	ø4	ø6
06	•				•			
07		•			•			
08		•				•		
18			•				•	
19				•			•	
20				•				•
25	•						•	
26		•					•	
27		•						•

#### Inch size

Mounting position	IN side				OUT	side		
Fitting type		Straight Elbow Note)		Stra		Elbov	N Note	
Symbol	ø5/32			ø1/4		ø1/4		
56	•				•			
57		•			•			
58		•				•		
68			•				•	
69				•			•	
70				•				•
75	•						•	
76		•					•	
77		•						•
82			•		•			
83				•	•			
84				•		•		

Note) Use caution to ensure the connector is not disturbed, depending on piping direction, when choosing to attach a digital pressure switch.

Panel nut

#### 3. Accessories

32 33 34

Symbol	None	Bracket	Pressure display	Panel nut	Decorative cover
Nil	•				
В		•		(●)	
G			•		
BG		•	•	(●)	
GP			•	•	
GPC Note 4)			•	•	•

Note 1) In case of a type with bracket, the panel nut is included.

Note 2) Pressure display means a pressure gauge or digital pressure switch is attached.


When choosing to attach a digital pressure switch is

chosen for attachment, be sure to enter the symbol, referring to table 6, "Digital Presure Switch Output Specifications". Otherwise, a pressure gauge will come with the regulator.

Additionally, pressure gauges are not compatible with copper-free and fluorine-free specifications.

Note 3) Not attachable to a model with digital pressure switch. Note 4) Please note that the dimensions will be bigger when GPC is selected.









#### 4. Semi-standard

Symbol	None	0.35 MPa setting Note 1)	Non- relieving	Note 2) Oil-free
Nil	•			
1		•		
2			•	
3				•
4		•	•	
5		•		•
6			•	•
7		•	•	•

Note 1) A pressure gauge with a full span of 0.4 MPa is attached Note 2) The oil-free specification is grease-free in the fluid contact area.

#### 5. Unit Representation

Symbol	Description
Nil	Display unit for product name plate and pressure gauge: MPa
<b>Z</b> Note 1, 2)	Display unit for product name plate and pressure gauge: psi
<b>ZA</b> Note 1, 3)	Digital pressure switch: with unit switching (MPa is initially set.)

Note 1) This option is available for use outside Japan only. (The SI unit has to be used in Japan.)

Note 2) The digital pressure switch is equipped with unit switching and initially set to

Note 3) This option is available with the digital pressure switch.

#### 6. Digital Presure Switch Output Specifications Note)

Symbol	Details	
Nil	None	
N	NPN open collector	
Р	PNP open collector	


Note) When a digital pressure switch is attached, the "pressure display" in table 3 "Accessories" be equipped.

The electrical entry is positioned on the side

opposite the handle

Weight

**Specifications** 



60 g

Note 1) 0.1 MPa or greater set pressure is required when used in the reverse flow. Note 2) 5 to 50°C when the digital pressure switch will be used.

Refer to page 676 for the digital pressure switch specifications.

## Symbol Relieving type

Non-relieving type

Note) A standard model is equipped with a backflow function. Main valve opens when the inlet pressure is released, and then the outlet pressure backflows into the inlet side.

#### **⚠** Specific Product Precautions

Be sure to read before handling.

Refer to front matter 43 for Safety Instructions and pages 365 to 369 for I Precautions on every series.

#### Maintenance

#### **∕**∿ Warning

1. Make sure to perform a periodic inspection of the pressure gauge when the compact manifold regulator is installed between a solenoid valve and an actuator. Sudden pressure changes could happen and the durability of the product could be reduced. Using an electronic style pressure gauge is recommended, depending on the situation.

ARJ AR425

to 935 ARX

AMR

ARM ARP

IR

IRV

VEX

SRH

SRP SRF

**VCHR** ITV

IC ITVX

PVO

72 g

VEF VEP


VER


VEA VY1


VBA VBAT


#### Series ARM10


#### Flow Characteristics (Representative Values)

















#### **Pressure Characteristics (Representative Values)**





#### Regulator Single Unit Type Series ARM10

#### Construction



**Component Parts** 


No.	Description	Material
1	Body	PBT
2	Bonnet	PBT
3	Handle	POM
4	Valve seat	POM
5	Adjusting screw assembly	Reinforced steel
6	Adjustment spring	Steel wire
7	Regulator clip	Stainless steel
8	Blanking plate assembly	_
9	Square nut	Steel

**Replacement Parts** 

No.	Description	Material	Part no.	Note
INO.	Description	ivialeriai		
Α	Diaphragm	Weatherproof	136126A	Relieving type
A	assembly	NBR, POM	136126-1A	Non-relieving type
В	Valve	HNBR, Aluminum alloy	136127-30#1	
С	Valve spring Stainless steel		136131	
D	O-ring	NBR	136146	Standard model
U	O-ring	HNBR	136146-30	Oil-free specification
Е	O-ring	NBR	136147	Standard model
-	O-ring	HNBR	136147-30	Oil-free specification
		NBR	136148	Standard model
F	0	HNBR	136148-30	Oil-free specification
-	F O-ring	NBR	KA01731	Standard model for digital pressure switch
		HNBR	KA01613	Oil-free spec. for digital pressure switch
G	Fitting assembly	_	Refer to page 687.	

#### **Dimensions**

 $ARM10-_{08}^{06}$ 



For dimensions and accessories of One-touch fittings, please refer to page 687. ARJ AR425 to 935

ARX AMR

ARM ARP

IR

IRV VEX

SRH

SRF VCHR

ITV IC

ITVX

PVQ VEF VEP

VEP


VEA VY1

VBA VBAT


#### Series ARM10

#### **Dimensions**

ARM10F1- $^{06}_{08}$ 




ARM10F1-06GPC



#### Panel cutout dimensions

4 x R1 or less




### Regulator/Single Unit Type **Options**


#### **Pressure Gauge**

Part no.	Pressure gauge indication range	Indication unit	
GC3-4A-X2101	0 to 0.4 MPa	MPa	
GC3-10A-X2101	0 to 1.0 MPa	IVIFA	
GC3-P4A-X2101	0 to 60 psi	psi	
GC3-P10A-X2101	0 to 150 psi	psi	

#### Specifications

Display accuracy	±3% F.S. (Full Span)	
Calibration angle	230°	
Limit indicator	With limit indicator	
Weight	17 g	






#### **Digital Pressure Switch**

Refer to page 676.

#### **Panel Nut**

Part no.	136133
Material	POM
Weight	1 g




#### **Decorative Cover**


Part no.	136155
Material	PBT
Weight	0.5 g



#### One-touch Fittings for Regulator







Fitting size	Х
ø4, ø5/32	2
ø6	2
ø1/4	6

AR425

to 935

ARX

AMR

ARM

ARP

IR

IRV

VEX SRH

SRP SRF

VCHR

ITV

IC


ITVX PVQ

VEF VEP VER

VEA

VY1 VBA VBAT

AP100



Fitting size	Х	Υ
ø4, ø5/32	10.5	21.5
ø6	10.5	22
ø1/4	10.5	24.5

#### ARM10F

Straight type



Fitting size	Х
ø4, ø5/32	7
ø6	7
ø1/4	11


type		
10.5		
×		
	\\	

Fitting size	Х	Υ
ø4, ø5/32	15.5	21.5
ø6	15.5	22
ø1/4	15.5	24.5

#### **Bracket**

Elbow

Part no.	136134#1
Material	Steel band (Zinc chromate
Weight	17 g



**SMC** 

#### Series ARM10F

### **Made to Order Specifications:**

Please contact SMC regarding detailed specifications, dimensions and delivery.



#### Regulator Single Unit Front Handle Type/ For Manifold

#### **Specifications**

Regulator construction		Direct acting	
Working principal		Diaphragm regulator	
Relief mechanism Star		Relief type	
Relief mechanism	Optional	Non-relieving type	
Backflow function		Within (Unbalance type)	
IN/OUT air passage diameter		ø4	
IN/OUT gasket sealing O.D.		ø7	
Proof pressure		1.5 MPa	
Maximum operating pressure		1.0 MPa	
Set pressure range Standard		0.05 to 0.7 MPa	
Set pressure range	Optional	0.05 to 0.35 MPa (Low pressure type)	
Fluid		Air	
Ambient and fluid temperature		5 to 60°C	
Weight		73 g	
Note 4) Torre monorable e bolto and torre Ordo			




Note 1) Two mounting bolts and two O-rings are attached.

Note 2) 0.1 MPa or greater set pressure is required when used in the reverse flow.

Note 3) 5 to 50°C when the digital pressure switch will be used. Refer to page 676 for the digital pressure switch specifications.

#### **How to Order**



a digital pressure switch.

#### 1. Accessory (Pressure Display)

Enter symbol for when the model requires		
Symbol	Accessory	
Nil	Without pressure display	
Α	A With pressure display	

Note 1) Pressure display means a pressure gauge or digital pressure switch is attached.

When choosing to attach a digital pressure switch is chosen for attachment, be sure to enter the symbol, referring to table 4, "Digital Presure Switch Output Specifications". Otherwise, a pressure gauge will come with the regulator.

Note 2) Pressure gauges are not compatible with copper-free and fluorine-free specifications.

#### 2. Semi-standard

Symbol	None	0.35 MPa setting Note 1)	Non-relieving	Oil-free Note 2)
Nil	•			
1		•		
2			•	
3				•
4		•	•	
5		•		•
6			•	•
7		•	•	•

Note 1) A pressure gauge with a full span of 0.4 MPa is attached

Note 2) The oil-free type has non-greased fluid contact areas.

#### 3. Unit Representation

Symbol	Description
Nil	Display unit for product name plate and pressure gauge: MPa
<b>Z</b> Note 1, 2)	Display unit for product name plate and pressure gauge: psi
<b>ZA</b> Note 1, 3)	Digital pressure switch: with unit switching (MPa is initially set.)

Note 1) This option is available for use outside Japan only. (The SI unit has to be used in Japan.)

Note 2) The digital pressure switch is equipped with unit switching and initially set to psi.

Note 2) The digital pressure switch is equipped with unit switching and initially set to psi Note 3) This option is available with the digital pressure switch.

#### Example



manifold base


4. Digital Presure Switch
Output Specifications Note)

Symbol	Details
Nil	None
N	NPN open collector
Р	PNP open collector

Note) When a digital pressure switch is attached, the "pressure display" in table 1 "Accessory" will be equipped.

The electrical entry is positioned on the side opposite the handle.

#### **Dimensions**









### Series ARM10/11 Blocks/Specific Product Precautions 1

Be sure to read before handling. Refer to front matter 43 for Safety Instructions and pages 365 to 369 for Precautions on every series.

#### Handling


#### **⚠** Warning

Observe the proper screw tightening torque in installation.

Tightening beyond the proper tightening torque may damage the mounting screws, blocks or switches.

If the force is below the tightening torque range, the threaded joint can come loose.


 Tightening torque for fixing screws and panel nuts of a single unit regulator



2. Tightening torque for regulator assembly fixing screws on regulator block



3. Tightening torque for blanking plates and pressure gauge fixing screws on regulator block



 Tightening torque for pressure switch fixing screws on common supply block with pressure switch and pressure switch block



5. Tightening torque for DIN rail clamp screws on end block  $$1.5\pm0.15~\text{N}{\cdot}\text{m}$$ 

#### **⚠** Warning

Digital Pressure Switch

Mount it with the proper screw-tightening torque.


Overtightening may damage the regulator body or adaptor, etc. Meanwhile, insufficient tightening may loosen the connecting threads.

- 1. Attach an O-ring to the regulator O-ring slit.
- Attach the adaptor with the 2 set screws by positioning the adapter slot on the opposite side of the handle and keeping the 2 square nuts (right/left) attached.

Tightening torque: 0.32 ± 0.03 N·m

- 3. Attach the switch body.
- 4. Fully insert the locking pin into the adapter slot. The switch body can be replaced by attaching/removing the

The switch body can be replaced by attaching/removing th locking pin.



ARJ

AR425 to 935

AMR

ARM

ARP IR

IRV

VEX

SRH

SRP

SRF

ITV IC

ITVX

PVQ VEF VEP

VER

VEA VY1

VBA VBAT AP100



### Series ARM10/11 Blocks/Specific Product Precautions 2

Be sure to read before handling. Refer to front matter 43 for Safety Instructions and pages 365 to 369 for Precautions on every series.

#### Handling

#### ⚠ Warning

#### Mounting and Removal of Manifold with DIN Rail


Be sure to shut off the power and air supplies before disassembly. Furthermore, since air may remain inside the actuator, piping and manifold, confirm that the air is completely exhausted before performing any work.

When disassembly and assembly are performed, air leakage may result if connections between blocks and tightening of the end block's holding screw are inadequate.

Before supplying air, confirm that there are no gaps between blocks, and that manifold blocks are securely fastened to the DIN rail. Then supply air and confirm that there is no air leakage before operating.


#### Removing blocks from DIN rail

- Loosen the end plate clamping screws on the side until they turn freely. (The screws do not come out.)
- Remove it by sliding it to the side (in the direction of the arrow).




#### Mounting blocks on DIN rail

- Confirm that the clamping screws of the end block on one side are securely tightened.
- Install blocks sliding them from the side. Push the end plate on the opposite side so that there will be no gap between blocks.
- 3. Tighten the end plate clamping screws on the opposite side.



#### Confirming DIN rail clasp

Confirm that the DIN rail clasps are securely hooked into the DIN rail.




#### 


#### One-touch fitting replacement

For the ease of replacement, One-touch fittings are installed as the cassette type. One-touch fittings are retained with clips inserted from the directions illustrated blow. Remove the clips with a flat head screw driver to replace the One-touch fittings. When installing, insert each One-touch fitting deeply to the end and reinsert the clip to the specified position.

#### 1. Single unit regulator



#### 2. Regulator block




#### 3. Various common supply blocks



#### Pressure supply of 3-way valve common supply block

Make sure that the handle is set at the OPEN or SHUT position in operation. The block cannot be used for the purpose of containing pressure because it allows a small amount of leakage.





### Series ARM10/11 Blocks/Specific Product Precautions 3

Be sure to read before handling. Refer to front matter 43 for Safety Instructions and pages 365 to 369 for Precautions on every series.

#### Handling


#### 

 Digital Pressure Switch How to attach a connector

Insert the connector vertically onto the pins, pinching the lever and connector with your fingers. Insert the lever into the switch body slot until it is locked. Cover the connector with a cover.

#### How to remove a connector

Displace the cover and pull the lever straight forward by pushing its claw to remove it from the slot.



#### **Adjustment**

#### **⚠** Caution

How to adjust indicator of the pressure gauge.

Make sure to follow the instruction when opening the lens cover to adjust the pressure gauge.

Open the lens cover to the arrow's direction with finger nail.



2. Adjust the gauge needle with for example, a flat head screw

driver.

Close the lens cover to the arrow's direction until it snaps on.



**SMC** 

ARJ AR425

to 935

AMR

ARM

ARP IR

IRV

VEX

SRH

SRF

ITV IC

PVO

VEF VEP

VER VEA

VY1

VBAT AP100



# Series ARM10/11 Pressure Switch Blocks Specific Product Precautions

Be sure to read before handling. Refer to front matter 43 for Safety Instructions and pages 365 to 369 for Precautions on every series.

**Design & Selection** 

#### 

1. Operate the switch only within the specified voltage.

Use of the switch outside the range of the specified voltage can cause malfunction and damage to the switch, it may also increase the risks of electrical shocks or fire.

- 2. Never apply a load above the maximum load capacity.

  It can damage the switch or shorten the service life.
- Be sure to observe the set pressure range and maximum operating pressure.

Use of the switch outside the set pressure range can cause failure and use beyond the maximum operating pressure can damage the switch.

#### Mounting

#### **⚠** Warning

 Do not use the switch unless the equipment operates normally.

After installation, repair or reform, connect air and electricity and conduct appropriate function and leakage tests to confirm proper installation.

Do not apply a tensile force to a cord.

Be sure to hold the body to handle the product.

Applying a tensile force to a cord may cause damage to the product.

3. Do not drop or bump the product.

Dropping or bumping while handling may cause damage to the product.

#### **Pressure Supply**

#### **⚠** Warning

1. Do not use the switch with corrosive gas or liquid.

Do not use the switch with corrosive gas or liquid. Such gas or fluid may cause damage to the switch.

2. Do not use the switch at a vacuum pressure.

If used in a vacuum pressure range, the switch will suction the outer air and become unable to operate.

#### **Pressure Setting**

#### **∧** Caution

- The switching setting indication scale shows the set value for pressure decrease.
- When the ON pressure signal is to be detected, the ON signal comes on at the pressure found by adding the hysteresis to the pressure set on the scale plate.
- The pressure indication on the scale plate is provided as a guideline. Use a pressure gauge to measure the precise settings.

#### Wiring

#### **⚠** Warning

1. Connect the load


Be sure to connect the load to the pressure switch before connecting the power supply.

2. Use a contact protection box.

If the load driven by the pressure switch is an induction load or connected with a lead wire of 5 m or longer, use a contact protection box in the following table.

Contact protection box	Operating voltage	Lead wire length
CD-P11	100 VAC	Switch connection side: 0.5 m
CD-P12	24 VDC	Load connection side: 0.5 m

3. Contact protection box internal circuit



#### 4. Contact protection box/Connection method

To connect the switch body and the contact protection box, connect the lead wire of the contact protection box on the side marked with "SWITCH" and the lead wire from the switch body. Connect the switch body and the contact protection box with a lead wire of 1 m or shorter and arrange them as close as possible.

#### 5. Lead wire dimensions

Covering: ø3.4 Insulator: ø1.1 Conductor: ø0.64

#### **Operating Environment**

#### **⚠** Warning

1. Never use in the presence of explosive gases.

These switches are not rated as explosion proof. Never use in the presence of an explosive gas as this may cause a serious explosion.

Do not use in an environment where a strong magnetic field is present.

The influence of the external magnetic filed may cause the switch to malfunction.

Do not use in an environment where the switch is exposed to water or oil splashes.

Because the switch has an open type construction, ingress of water or oil can corrode the electric circuit, resulting in malfunction and damage.

4. Do not apply vibration to the switch.

If vibration is applied, malfunction or setting errors may result.