Compact Cylinder With Solenoid Valve

CVQ Series

ø32, ø40, ø50, ø63

Valve and compact cylinder integrated for compactness $C \in$

UK CA







CVQ
CVQM
CVJ□
CVM
CV3
CVS1
MVGQ

Solenoid valve

Compact cylinder

Labor saving • No need to select size of valve

Less piping work

Energy saving Air consumption between the valve and

cylinder reduced by approximately 50%.

Space saving

Small mounting space with valve integrated structure



Easy Mounting



Variation

Bore size		Standard stroke (mm)										
(mm)	5	10	15	20	25	30	35	40	45	50	75	100
32												
40	٠		•	•	٠		•	•	٠	•	٠	٠
50	-		•								٠	
63	—	•	•	•	•	•	•	•	•	•	•	•



Applicable Auto Switches / Refer to pages 941 to 1067 for detailed auto switch specifications

			ro			Load vol	tage	Auto swite	ch model	Lead w	ire ler	ngth(m)*				
Туре	Special function	Electrical entry	dicato	Wiring (Output)				Electrical entry		0.5	1	3	5	Pre-wired connector		icable	
	luncuon	enuy	<u> </u>	(Output)		DC	AC	Perpendicular	In-line	(Nil)	(M)	(L)	(Z)	CONTROLO	load		
÷				3-wire (NPN)		5 V. 12 V		M9NV	M9N	٠	•	٠	0	0	IC circuit		
switch				3-wire (PNP)		5 V, 12 V		M9PV	M9P	•	•	٠	0	0			
				2-wire		12 V		M9BV	M9B	۲	٠	٠	0	0	_		
auto	Diagnostic	indication Grommet Ver			3-wire (NPN)		5 V. 12 V		M9NWV	M9NW	•	•	•	0	0	IC circuit	Relay,
	(2-color)		Yes	3-wire (PNP)	24 V 5 V, 12 V 12 V	—	M9PWV	M9PW	•	•	٠	0	0		PLC		
state	(indicator)			2-wire		12 V		M9BWV	M9BW	۲	٠	٠	0	0	-	1 20	
	Water			3-wire (NPN)		5 V. 12 V		M9NAV*1	M9NA*1	0	0	•	0	0	IC circuit		
Solid	resistant 2-color			3-wire (PNP)		5 V, 12 V		M9PAV*1	M9PA*1	0	0	٠	0	0			
	(indicator)			2-wire		12 V		M9BAV*1	M9BA*1	0	0	٠	0	0	-		
it _			Yes	3-wire (NPN equivalent)	_	5 V	_	A96V	A96	•	—	•	—	—	IC circuit	—	
Reed auto switch		Grommet	res	2-wire	24 V	12 V	100 V	A93V*2	A93	•	•	٠	۲	-		Relay,	
art –			_	∠-wire	24 V	5 V, 12 V	100 V or less	A90V	A90	۲	—	٠	—	—	IC circuit	PLC	

*1 Water resistant type auto switches can be mounted on the above models, but in such case SMC cannot guarantee water resistance. Consult with SMC regarding water resistant types with the above model numbers.

*2 1 m type lead wire is only applicable to D-A93.

* Lead wire length symbols: 0.5 m Nil (Example) M9NW M9NWM

1 m M

5 m Z

- 3 m L
 - MANMI
 - MONIN/7
- * Solid state auto switches marked with "O" are produced upon receipt of order. * For details about auto switches with pre-wired connector, refer to pages 1014 and
- 1015
- * Auto switches are shipped together (not assembled).
- ∕∂SMC

D-🗆

-X□

CVQ Series



∧Caution

Do not separate the cylinder from the valve.

Symbol

With valve (Rubber bumper)



Theoretical Output

		•			
				Unit: N	
Bore size	Operating	Operatir	ng pressur	e (MPa)	
(mm)	direction	0.3	0.5	0.7	
32	IN	181	302	422	
52	OUT	241	402	563	
40	IN	317	528	739	
40	OUT	377	628	880	
50	IN	495	825	1150	
50	OUT	589	982	1370	
63	IN	840	1400	1960	
03	OUT	936	1560	2184	

Mounting Bracket Part No.

East Note)	Flongo	Double
FOOL	Flange	clevis
CVQ-L032	CVQ-F032	CVQ-D032
CVQ-L040	CVQ-F040	CVQ-D040
CQ-L050	CQ-F050	CVQ-D050
CVQ-L063	CVQ-F063	CVQ-D063
	CVQ-L032 CVQ-L040 CQ-L050	Foot Note Flange CVQ-L032 CVQ-F032 CVQ-L040 CVQ-F040 CQ-L050 CQ-F050

Note) Order two foot brackets per cylinder.

* Parts belonging to each bracket are as follows. Foot, Flange: Body mounting screws Double clevis: Clevis pin, C-type retaining ring for

shaft, Body mounting screws

Accessory bracket

For details about the single knuckle joint, double knuckle joint, knuckle pin, rod end nut, and simple joint, refer to page 735.

Cylinder Specifications

Bore size (mm)	32	32 40 50 63						
Action		Double actin	g, single rod					
Fluid		Air (No	n-lube)					
Proof pressure	1.0 MPa							
Maximum operating pressure	0.7 MPa							
Minimum operating pressure	0.15 MPa							
Ambient and fluid temperature	re -10 to 50°C (No freezing)							
Stroke tolerance	0 to +1.0 mm*							
Mounting method	Through-hole / Both ends tapped							
Piston speed	50 to 500 mm/s							
Cushion	Rubber bumper							

* Stroke length tolerance does not include variations in the bumper value.

Valve Specifications

Type of actuation	2 position single
Manual override	Non-locking push type / Locking slotted type
Pilot exhaust	Main/Pilot valve common exhaust type
Mounting orientation	Unrestricted (based on cylinder mounting orientation)
Enclosure	Dustproof

Solenoid Specifications

Electrical entry		M-type plug connector				
Coil rated voltage DC		24/12 (V)				
Allowable voltage fluctuation Not	ie)	±10% of the rated voltage				
Power consumption DC		0.35 (With light: 0.4) W				
Surge voltage suppressor		Diode (Non-polar type: Varistor)				
Indicator light		LED				

Note) The S and Z types of surge voltage suppressor have an internal circuit allowing voltage drop, so use within the following allowable voltage fluctuation range. S, Z type 24 VDC: -7% to +10% 12 VDC: -4% to +10%

Standard Stroke

	(mm)
Bore size (mm)	Standard stroke
32 *1	5, 10, 15, 20, 25, 30, 35, 40, 45, 50, 75, 100
40	5, 10, 15, 20, 25, 30, 35, 40, 45, 50, 75, 100
50 *2	10, 15, 20, 25, 30, 35, 40, 45, 50, 75, 100
63	10, 15, 20, 25, 30, 35, 40, 45, 50, 75, 100

*1 The outline dimensions for 5 mm stroke will be the same as those for 10 mm stroke.

*2 The outline dimensions for 10 mm stroke will be the same as those for 15 mm stroke.

Intermediate Stroke

SMC

Part no.	Refer to "How to Order" for standard model numbers (previous page).								
	Intermediate strokes are available by using spacers with standard stroke cylinders.								
Description	Bore size	Description							
Description	32	Compatible with strokes of 1 mm increments.							
	40, 50, 63	Compatible with strokes of 5 mm increments.							
Stroke	Bore size	Stroke range							
range (mm)	32	1 to 99							
range (mm)	40, 50, 63	5 to 95							
Applicable example	Part no.: CVQB32-95-□ A spacer of 5 mm is installed in standard cylinder CVQB32-100-□. B dimension is 133 mm.								



Weight

Weight	S											Unit (g)
Bore size	Stroke											
(mm)	5	10	15	20	25	30	35	40	45	50	75	100
32	295	288	310	332	354	376	398	420	442	464	575	686
40	365	391	417	443	469	495	521	547	573	599	726	853
50	_	735	721	760	800	839	879	918	958	997	1195	1392
63	_	863	905	947	990	1032	1074	1116	1158	1200	1411	1621

Calculation: (Example) CVQB32-20M

332 g Additional weight: Rod end male thread 43 g

CVQ
CVQM
CVJ🗆
CVM
CV3
CVS1
MVGQ

(mm)

Additional Weight Unit									
Bore size (mm)		32	40	50	63				
Axial piping		5	5	4	4				
Connector (300 mm)		3	3	3	3				
Rod end male thread	Male thread	26	27	53	53				
Rod end male triread	Nut	17	17	32	32				
With boss in head end		5	7	13	25				
Foot (including mounting bolt)		148	160	243	334				
Rod flange (including mounting bolt)		185	219	373	569				
Head flange (including mounting bolt)		170	203	348	544				
Double clevis (including pin, retain	ing ring, bolt)	156	201	399	574				

Mounting Bolt for CVQ

Refer to the following for ordering procedures. Order the actual number of bolts that will be used.

Example) CQ- M5 x 45L: 4 pcs.

(mm									
Cylinder model	С	D	Mounting bolt size						
CVQB32- 5		45	CQ- M5 x 45L						
- 10		45	x 45L						
- 15		50	x 50L						
- 20		55	x 55L						
- 25		60	x 60L						
- 30	9	65	x 65L						
- 35	3	70	x 70L						
- 40]	75	x 75L						
- 45		80	x 80L						
- 50		85	x 85L						
- 75		110	x 110L						
-100		135	x 135L						
CVQB40- 5		45	CQ- M5 x 45L						
- 10		50	x 50L						
- 15		55	x 55L						
- 20		60	x 60L						
- 25		65	x 65L						
- 30	7.5	70	x 70L						
- 35] ′.5	75	x 75L						
- 40		80	x 80L						
- 45		85	x 85L						
- 50		90	x 90L						
- 75]	115	x 115L						
-100		140	x 140L						

	Mounting bolt
. D	. Ŭ .

M

(mm								
Cylinder model	С	D	Mounting bolt size					
CVQB50- 10		60	CQ- M6 x 60L					
- 15	12.5	60	x 60L					
- 20		65	x 65L					
- 25		70	x 70L					
- 30		75	x 75L					
- 35	12.5	80	x 80L					
- 40		85	x 85L					
- 45		90	x 90L					
- 50		95	x 95L					
- 75		120	x 120L					
-100		145	x 145L					
CVQB63- 10		60	CQ- M8 x 60L					
- 15		65	x 65L					
- 20		70	x 70L					
- 25		75	x 75L					
- 30		80	x 80L					
- 35	14.5	85	x 85L					
- 40		90	x 90L					
- 45		95	x 95L					
- 50		100	x 100L					
- 75		125	x 125L					
-100		150	x 150L					

D-🗆 -X🗆

CVQB32-20----Basic weight:

³⁷⁵ g

Mounting: Be sure to use it as through-hole when mounting.

Allowable Kinetic Energy

Rod End Allowable Lateral Load



Relationship between Number of Needle Rotations and Piston Speed



Restrictor: ASN2-M5

Pressure: 0.5 MPa

Mounting orientation: Horizontal, with no load, piston extended

* The above piston speed is for reference purpose only.



The allowable lateral load applied to the rod end is as shown above. Do not use exceeding the value shown by the graph.



Restrictor: ASN2-01

Pressure: 0.5 MPa

SMC

Mounting orientation: Horizontal, with no load, piston extended

* The above piston speed is for reference purpose only.

<exhaust restrictor="" silencer="" with=""></exhaust>

_	Applicable bore size (mm)	Model	Port size	Effective area (mm ²)	Weight (g)
and the second s	32, 40	ASN2-M5	M5 x 0.8	1.8	5
	50, 63	ASN2-01	1/8	3.6	17

Construction



Basic Type

Component Parts

COII	ipolient Faits		
No.	Description	Material	Note
1	Cylinder tube	Aluminum alloy	Hard anodized
2	Piston	Aluminum alloy	
3	Piston rod	Carbon steel	Hard chrome plated
4	Collar	Aluminum alloy casting	ø50, ø63, chromate coating
4	Collar	Aluminum alloy	Anodized
5	Retaining ring	Carbon tool steel	Phosphate coated
6	Bushing	Bearing alloy	ø50, ø63
7	Bumper A	Urethane	
8	Bumper B	Urethane	
9	Magnet	_	
10	Rod seal	NBR	
11	Piston seal	NBR	
12	Gasket	NBR	
13	Solenoid valve	—	
14	Pilot valve	_	
15	Boss ring	Aluminum alloy	Hard anodized
16	Rod end nut	Carbon steel	Nickel plated

Replacement parts: Seal Kit

Bore size	Order no.	Contents		
32	CQ2B32-PS			
40	CQ2B40-PS	Set of nos. above		
50	CQ2B50-PS	101112		
63	CQ2B63-PS	1		

* Seal kit includes (1), (1), (2). Order the seal kit, based on each bore size.

* Grease pack must be ordered separately as it is not included in the seal kit.

Grease part no.: GR-S-010 (10 g)

How to Order Pilot Valve Assembly







6

Rod end male thread



CVQ
CVQM
CVJ□
CVM
CV3
CVS1
MVGQ



Length of plug connector lead wire

The standard length of the plug connector with a lead wire is 300 mm, but other lengths are available as follows.

How to Order Connector Assembly

With lead wire: SY100-30-4A-

	Le	ad wi	re length 🜢
Nil	300 mm	20	2000 mm
6	600 mm	25	2500 mm
10	1000 mm	30	3000 mm
15	1500 mm	50	5000 mm

How to Order

SMC

Indicate the part number of the connector assembly in addition to the part number of the solenoid valve without the connector for the plug connector. Example) Lead wire length 2000 mm

When ordering cylinder with valve CVQB32-30-M9B-5MOZ SY100-30-4A-20



CVQ Series

Dimensions: ø32, ø40, ø50, ø63

Basic: CVQB



Bore size (mm)	Stroke range (mm)	RA	RB	s	v	w	Y	
32 5 to 100		10	7	12	43	43.5	59	
40	5 to 100	10	7	12	43	43.5	67	
50	10 to 100	14	8	17	54	63	83	
63	10 to 100	18	10.5	17	54	63	97	

Note 1) The dimensions (A + stroke) and (B + stroke) for 5 mm stroke will be the same as those for 10 mm stroke.

Note 2) The dimensions (A + stroke) and (B + stroke) for 10 mm stroke will be the same as those for 15 mm stroke



Dimensions: ø32, ø40, ø50, ø63

Foot: CVQL





															(mm)
Bore size (mm)	Stroke range (mm)	A	в	LS	L	L1	LD	LG	LH	LT	LX	LY	LZ	х	Y
32	5 to 100	57.2 Note 1)	33 Note 2)	17 Note 1)	17	38.5	6.6	4	30	3.2	57	66.5	71	11.2	5.8
40	5 to 100	63.7	39.5	23.5	17	38.5	6.6	4	33	3.2	64	74	78	11.2	7
50	10 to 100	66.7 Note 2)	40.5 Note 2)	17.5 Note 2)	18	43.5	9	5	39	3.2	79	90	95	14.7	8
63	10 to 100	72.2	46	20	18	43.5	11	5	46	3.2	95	104.5	113	16.2	9

Rod end male thread

CVQ
CVQM
CVJ□
CVM
CV3
CVS1
MVGQ

Foot bracket material: Carbon steel Surface treatment: Nickel plated

Note 1) The dimensions (A + stroke), (B + stroke) and (LS + stroke) for 5 mm stroke will be the same as those for 10 mm stroke. Note 2) The dimensions (A + stroke), (B + stroke) and (LS + stroke) for 10 mm stroke will be the same as those for 15 mm stroke.

Rod flange: CVQF





(----)

Rod end male thread



											(mm)	
Bore size (mm)	Stroke range (mm)	A	в	FD	FT	FV	FX	FZ	L	Lı	м	
32	5 to 100	50 Note 1)	33 Note 1)	5.5	8	48	56	65	17	38.5	34	
40	5 to 100	56.5	39.5	5.5	8	54	62	72	17	38.5	40	
50	10 to 100	58.5 Note 2)	40.5 Note 2)	6.6	9	67	76	89	18	43.5	50	- Flange bracket material: Carbon stee
63	10 to 100	64	46	9	9	80	92	108	18	43.5	60	Surface treatment: Nickel plated

Note 1) The dimensions (A + stroke) and (B + stroke) for 5 mm stroke will be the same as those for 10 mm stroke. Note 2) The dimensions (A + stroke) and (B + stroke) for 10 mm stroke will be the same as those for 15 mm stroke.



Dimensions: ø32, ø40, ø50, ø63

Head flange: CVQG







Rod end male thread

											(mm)
Bore size (mm)	Stroke range (mm)	A	в	FD	FT	FV	FX	FZ	L	Lı	м
32	5 to 100	48 Note 1)	33 Note 1)	5.5	8	48	56	65	7	28.5	34
40	5 to 100	54.5	39.5	5.5	8	54	62	72	7	28.5	40
50	10 to 100	57.5 Note 2)	40.5 Note 2)	6.6	9	67	76	89	8	33.5	50
63	10 to 100	63	46	9	9	80	92	108	8	33.5	60

Flange bracket material: Carbon steel

Surface treatment: Nickel plated

Note 1) The dimensions (A + stroke) and (B + stroke) for 5 mm stroke will be the same as those for 10 mm stroke. Note 2) The dimensions (A + stroke) and (B + stroke) for 10 mm stroke will be the same as those for 15 mm stroke.

Double clevis: CVQD



														(mm)
Bore size (mm)	Stroke range (mm)	A	в	CL	CD	ст	CU	cw	сх	cz	L	Lı	N	RR
32	5 to 100	70 Note 1)	33 Note 1)	60	10	5	14	20	18	36	7	28.5	M6 x 1	10
40	5 to 100	78.5	39.5	68.5	10	6	14	22	18	36	7	28.5	M6 x 1	10
50	10 to 100	90.5 Note 2)	40.5 Note 2)	76.5	14	7	20	28	22	44	8	33.5	M8 x 1.25	14
63	10 to 100	98	46	84	14	8	20	30	22	44	8	33.5	M10 x 1.5	14

Double clevis bracket material: Cast iron Surface treatment: Coated

Note 1) The dimensions (A + stroke), (B + stroke) and (CL + stroke) for 5 mm stroke will be the same as those for 10 mm stroke. Note 2) The dimensions (A + stroke), (B + stroke) and (CL + stroke) for 10 mm stroke will be the same as those for 15 mm stroke.

Accessory Bracket

Single knuckle joint



aterial:	Cast	iron
	(1	mm)

M

Part no.	Applicable bore size (mm)	A	A 1	E1	Lı	ММ	^R R₁	U1	ND _{H10}	NX
I-G04	32, 40	42	14	ø22	30	M14 x 1.5	12	14	10+0.058	18-0.3
I-G05	50, 63	56	18	ø28	40	M18 x 1.5	16	20	14 ^{+0.070}	22 ^{-0.3}

Knuckle pin (Common with double clevis pin)



Part no.	Applicable bore size (mm)	Dd9	L	d	Lı	m	t	Retaining ring
IY-G04	32, 40	10-0.040	41.6	9.6	36.2	1.55	1.15	10 C-type for shaft
IY-G05	50, 63	14-0.050	50.6	13.4	44.2	2.05	1.15	14 C-type for shaft

Simple Joint / Ø32 to Ø63

Joint and mounting bracket (A/B-type) part no.



Allowable Eccentricity

Bore size	ø 32	ø 40	ø 50	ø 63
Eccentricity tolerance		±	1	
Backlash		0	.5	

<Ordering>

· Joints are not included with the A- or B-type mounting brackets Order them separately,

(Example) Bore size for ø40

- Order number · A-type mounting bracket part number YA-03
- Joint YU-03

Joint and mounting bracket (A/B-type) part no.

Bore size (mm)	Joint part no.	Applicable mounting bracket					
Bore size (mm)	Joint part no.	A-type mounting bracket	B-type mounting bracket				
32, 40	YU-03	YA-03	YB-03				
50, 63	YU-05	YA-05	YB-05				



	UA	<u>, c</u>		-			-	(Nic		ated) (mm)
Part no.	Applicable bore size (mm)	UA	С	d١	d2	н	к	L	UT	Weight (g)
YU-03	32, 40	17	11	15.8	14	M8 x 1.25	8	7	6	25
YU-05	50, 60	17	13	19.8	18	M10 x 1.5	10	7	6	40



					(mm)	
Part no.	Applicable bore size (mm)	d	н	в	с	
NT-04	32, 40	M14 x 1.5	8	22	25.4	
NT-05	50, 63	M18 x 1.5	11	27	31.2	Ľ

2 x ø**D**

CVM CV3 CVS1 MVGQ



aterial: Chromium
nolybdenum steel
(Nickel plated)
(mm)

Part no.	Bore size (mm)	в	D	Е	F	м	T 1	T ₂
YA-03	32, 40	18	6.8	16	6	42	6.5	10
YA-05	50, 63	20	9	20	8	50	6.5	12
Part no.	Bore size (mm)	U	v	w	Weight (g)			
YA-03	32, 40	6	18	56	55			
YA-05	50, 63	8	22	67	100			

B-type mounting bracket

A-type mounting bracket



SMC

735

D-

-X□

CVQ Series Auto Switch Mounting

Auto Switch Proper Mounting Position (Detection at Stroke End) and Its Mounting Height



Bore size (mm)	D-M9□ D-M9□W			D-M9□V, D-M9□WV D-M9□AV		D-M9□A		D-A9□			D-A9⊡V				
	Α	В	w	Α	В	Hs	Α	В	w	Α	В	w	Α	в	Hs
32	12 [17]	9	1	12 [17]	9	29	12 [17]	9	3	8 [13]	5	-3 (-0.5)	8 [13]	5	27
40	16	11.5	-1.5	16	11.5	32.5	16	11.5	0.5	12	7.5	-5.5 (-3)	12	7.5	30.5
50	14 <19>	14.5	-4.5	14 <19>	14.5	38.5	14 <19>	14.5	-2.5	10 <15>	10.5	-8.5 (-6)	10 <15>	10.5	36.5
63	16.5	17.5	-7.5	16.5	17.5	42	16.5	17.5	-5.5	12.5	13.5	-11.5 (-9)	12.5	13.5	40

The value in parentheses [] is for 5 mm stroke with ø32.

The value in parentheses < > is for 10 mm stroke with ø50.

(): Denotes the values for D-A93

* The negative indication in the table for W shows the mounting inside the cylinder body.

* For the actual setting, check the operating condition of the auto switch and adjust.

Auto Switch Mountable Surface, Mounting Groove Number (Direct Mounting)

The below table shows which surfaces of the cylinder an auto switch can be mounted on, and the number of slots for the direct mounting type auto switch.



ra	an auto switch can be mounted on, and the number of slots for the direct mo										
	Switch model	D-M9□(V), M9□W(V), M9□A(V), A9□(V)									
	Bore size (mm)	A (Mounting groove number)	A B (Mounting groove number) groove number)		D (Mounting groove number)						
	32	—	(2)	(2)	(2) (2) (2) (2) (2)						
	40	—	(2)	(2)							
	50	—	(2)	(2)							
	63	—	(2)	(2)	(2)						

Auto Switch Mounting

Operating Range

				(mm)				
Auto switch model	Bore size							
Auto switch model	32	40	50	63				
D-M9□, D-M9□V D-M9□W, D-M9□WV D-M9□A, D-M9□AV	6	6	7	7.5				
D-A9□, D-A9□V	9.5	9.5	9.5	11.5				

 Since this is a guideline including hysteresis, not meant to be guaranteed. (Assuming approximately ±30% dispersion.)
 There may be the case it will vary substantially depending on an ambient

environment.

Minimum Stroke for Auto Switch Mounting

							(mm)		
Bore size (mm)	No. of auto switch mounted	D-M9□	D-M9□V		D-M9⊟WV D-M9⊟AV	D-A9□	D-A9⊡V		
32* ¹ , 40	With 1 pc.	10 (5)	5	15 (10)	10	10 (5)	5		
50* ² , 63	With 2 pcs.	10 (5)	5	15	15	10	10		
A The subline dimensions for 5 mm shalls will be the same of these for 40 mm shalls									

*1 The outline dimensions for 5 mm stroke will be the same as those for 10 mm stroke.

*2 The outline dimensions for 10 mm stroke will be the same as those for 15 mm stroke.

*3 (): Mountable minimum stroke when the auto switch protrudes from the cylinder body end face and does not interfere with the space for the lead wire. (The figure on the right) Order separately for auto switches.

Refer to page 1062.





CVQ Series Specific Product Precautions 1

Be sure to read this before handling the products. Refer to back page 50 for Safety Instructions, pages 3 to 12 for Actuator and Auto Switch Precautions, and 3/4/5 Port Solenoid Valve Precautions in Best Pneumatics No. 1-1.

Manual Override

MWarning

Connected actuator is started by manual operation. Use the manual override after confirming that there is no danger.

Non-locking push type [Standard]

Press in the direction of the arrow



arrow.

Locking slotted type

Turn 90° in the direction of

[B type]

▲ Caution

When operating with a screwdriver, turn it gently using a watchmaker's screwdriver. (Torque: Less than 0.1 N·m)

How to Use Plug Connector

≜Caution

1. Attaching and detaching connectors

- To attach a connector, hold the lever and connector unit between your fingers and insert straight onto the pins of the solenoid valve and remove the pawl from the groove by pushing the lever downward with your thumb, and pull the connector straight out.
- To detach a connector, remove the pawl from the groove by pushing the lever downward with your thumb, and pull the connector straight out.



2. Crimping of lead wires and sockets

Not necessary if ordering the lead wire pre-connected model. Strip 3.2 to 3.7 mm at the end of the lead wires, insert the ends of the core wires evenly into the sockets, and then crimp with a crimping tool. When this is done, take care that the coverings of the lead wires do not enter the core wire crimping area.

For crimping, use a specific tool. (For special crimping tool, please contact SMC.)



How to Use Plug Connector

▲Caution

2. Attaching and detaching sockets with lead wires • Attaching

Insert the sockets into the square holes of the connector (\oplus, \bigcirc) indication), and continue to push the sockets all the way in until they lock by hooking into the seats in the connector. (When they are pushed in, their hooks open and they are locked automatically.) Then confirm that they are locked by pulling lightly on the lead wires.

Detaching

To detach a socket from a connector, pull out the lead wire while pressing the socket's hook with a stick having a thin tip (approx.1 mm). If the socket will be used again, first spread the hook outward.



Do not apply bending force or tensile force repeatedly to the lead wire.

This can cause disconnection of the connector and breakage of the lead wire. If this is unavoidable due to the application, keep the bending radius of the lead wire R8 mm at least.

Surge Voltage Suppressor

Standard (with polarity) With surge voltage suppressor (□S)

Diode to prevent reverse current



With light/surge voltage suppressor (
Z)





■ Non-polar type

With surge voltage suppressor (
R)



With light/surge voltage suppressor (□U)

 For standard type, connect so that polarity is matched to the connector's (+), (-). (For non-polar type, the lead wires can be connected to either one.)

 Solenoids, whose lead wires have been pre-wired: positive side red and negative side black. CVO

D-

-X□



SOL.a (-,+)^O



CVQ Series Specific Product Precautions 2

ÌSMC

Be sure to read this before handling the products. Refer to back page 50 for Safety Instructions, pages 3 to 12 for Actuator and Auto Switch Precautions, and 3/4/5 Port Solenoid Valve Precautions in Best Pneumatics No. 1-1.

Retaining Ring Installation/Removal

∆Caution

- To remove and install the retaining ring, use an appropriate pair of pliers (tool for installing C-type retaining ring).
- 2. Even if a proper plier (tool for installing C-type retaining ring) is used, it is likely to inflict damage to a human body or peripheral equipment, as a retaining ring may be flown out of the tip of a plier (tool for installing C-type retaining ring). Be much careful with the popping of a retaining ring. Besides, be certain that a retaining ring is placed firmly into the groove of rod cover before supplying air at the time of installment.

Other

1. Do not separate the cylinder from the valve.

Mounting/Removal

1. Do not remove the plug from the cylinder tube end surface.

If the plug is removed with compressed air supplied to the cylinder, the air blowing out may inflict damage to a human body or peripheral equipment.