

# 5 Port Solenoid Valve Series VF1000/3000/5000



# Power consumption is reduced by power saving circuit.

Power consumption is decreased by approx. 1/3 by reducing the wattage required to hold the valve in an energized state. (Effective energizing time is over 40 ms at 24 VDC.) Refer to electrical power waveform as shown below.




Noise is considerably reduced by changing it to DC mode with a full-wave rectifier.

# •Reduced apparent power Conventional: $5.6 \text{ vA} \rightarrow 1.55 \text{ vA}$

#### Built-in strainer in the pilot valve Unexpected troubles due to foreign matter can be prevented.

Unexpected troubles due to foreign matter can be prevented. Note) Be sure to mount an air filter on the inlet side.




SV SYJ SZ VF VP4 S0700 VO V04 V05 VOC VOC4 VOZ SO VFS VFR V07



## Model Selection by Operating Conditions (1)

### Solenoid Valve: Single Unit





# Model Selection by Operating Conditions (2)

### Solenoid Valve: Manifold

	Series	EXH port type		Manifold base model	Applicable valve	Applicable stations		
	VF1000		VV5F1-30	A TRANS				SJ
		Common EXH		4(A), 2(B) port M5, 1/8				SY
		COMMONEAR		5/3(R) port				SY SV
	11117			1(P) port / 1/8	VF1□30 VF1□33	2 to 20 stations		SYJ
			VV5F1-31	4(A), 2(B) port M5, 1/8	VFIL33	Stations		SZ
		Individual EXH						VF
				5(EA), 3(EB) port				VP4
	VF3000		VV5F3-30	4(A), 2(B) port				S0700
rted				1/8, 1/4				VQ
d y po	C mark	Common EXH		5(R), 3(R) port 1/4	VF3⊡30 VF3⊡33	2 to 20 stations		VQ4
Bo	a wa			1(P) port				VQ5
	VF5000		VV5F5-20	1/4 4(A), 2(B) port				VQC
		Common EXH		5(R), 3(R) port		2 to 10		VQC4
				3/8		stations		VQZ
				1(P) port 3/8	VF5□20			SQ
		Common EXH	VV5F5-21	5(R), 3(R) port	VF5⊡23	2 to 15		VFS VFR
								VCN VQ7
				1/2		stations		VQI
				1(P) port 1/2				
	VF3000		VV5F3-40	5(R), 3(R) port				
	(FFFF	Common EXH			VF3□40 VF3□43	2 to 20 stations		
ted				1(P) port 1/4 4(A), 2(B) port	VF3L43	Stations		
Base moun	VF5000		VV5F5-40	1/4			Page 848	
Base	VF5000		VV3F3-40	5(R), 3(R) port 3/8				
		Common EXH		1(P) port	VF5⊡44	2 to 10 stations		
				3/8 4(A), 2(B) port				
			L	1/4			17	



# Cylinder Speed Chart (1)

Use as a guide for selection. Please check the actual conditions with SMC Model Selection Program.

#### **Body Ported** Bore size Series CS1 Series CJ2 Series CM2 Series MB, CA2 Average Pressure 0.5 MPa Pressure 0.5 MPa Pressure 0.5 MPa Pressure 0.5 MPa Series speed Load factor 50% Load factor 50% Load factor 50% Load factor 50% (mm/s) Stroke 60 mm Stroke 300 mm Stroke 500 mm Stroke 1000 mm ø25 ø32 ø50 ø63 ø100 ø125 ø140 ø160 ø6 ø10 ø16 ø20 ø40 ø40 ø80 1000 Perpendicular, 800 upward actuation 600 VF1120-01 Horizontal actuation 400 200 0 1000 800 600 VF3130-02 400 200 0 1000 800 600 VF5120-03 400 200 0

∗ With ★: when using steel piping

#### **Base Mounted**

									В	ore siz	e							
Series	Average speed (mm/s)	Series CJ2 Pressure 0.5 MPa Load factor 50% Stroke 60 mm		Series CM2 Pressure 0.5 MPa Load factor 50% Stroke 300 mm			Series MB, CA2 Pressure 0.5 MPa Load factor 50% Stroke 500 mm				Series CS1 Pressure 0.5 MPa Load factor 50% Stroke 1000 mm							
	ø6 ø10 ø16 ø20 ø25 ø32 ø40 ø40				ø50	ø63	ø80	ø100	ø125	ø140	ø160	ø180	ø200					
VF3140-03	1000 800 600 400 200 0													*	╢╝╹	•	dicular, actuati tal actu	on -
VF5144-04	1000 800 600 400 200 0														*	*	*	*

\* With \*: when using steel piping

# Cylinder Speed Chart 2

#### Conditions

Use as a guide for selection. Please check the actual conditions with SMC Model Selection Program.

SJ

S0700

VQ VQ4 VQ5 VQC

VQ7

#### **Body Ported**

E	Body ported	Series CJ2	Series CM2	Series MB, CA2	Series CS1		
	Tubing x Length	T0604 x 1 m	T080	6 x 1 m	_		
VF1120-01	Speed controller	AS3002F-06	AS30	-			
	Silencer		AN101-01				
	Tubing x Length	T0604 x 1 m	_				
VF3130-02	Speed controller	AS3002F-06	AS40	_			
	Silencer		AN110-01				
	Tubing x Length	T0604 x 1 m	T1075 x 1 m	T120	9x1m		
VF5120-03	Speed controller	AS3002F-06	AS3002F-06 AS4002F-10 AS400				
	Silencer		AN30-03		AN302-03		

#### Body Ported [when using SGP (Steel Piping)]


E	Series CS1			
	Tubing x Length	SGP10A x 1 m		
VF5120-03	Speed controller	AS420-03		
	Silencer	AN30-03		

#### **Base Mounted**

Ba	ase mounted	Series CJ2	Series MB, CA2	Series CS1	VQC4			
	Tubing x Length	T0604 x 1 m	T1075 x 1 m	T1209 x 1 m	—	VQZ		
VF3140-03	Speed controller	AS3002F-06	AS4002F-10	AS4002F-12	—	T QL		
	Silencer	—	SQ					
	Tubing x Length	T0604 x 1 m	T1075 x 1 m	T1209	)x1m	VFS		
VF5144-04	Speed controller	AS3002F-06 AS4002F-10			)2F-12	VFS		
	Silencer	AN40-04						

#### Base Mounted [when using SGP (Steel Piping)]

Ba	ase mounted	Series CS1
	Tubing x Length	SGP10A x 1 m
VF3140-03	Speed controller	AS420-03
	Silencer	AN30-03
	Tubing x Length	SGP15A x 1 m
VF5144-04	Speed controller	AS420-04
	Silencer	AN40-04



\* Refer to page 857 for details on the DIN (EN175301-803) terminal. Note 1) When using IP65, select the main/pilot valve common exhaust type. (Except VF1000)

Note 2) With the same specifications as the DC type, all electrical entries for the 24 VAC type are CE marking compliant.



residual voltage will remain. Refer to page 858

for details.





Made to Order

(Refer to page 821 for details.)

Pilot exhaust port with piping

thread (M3) specification

TRIAC output specification

Specification

	Mo	del	VF1000	VF3000	VF5000			
Fluid				Air				
Operating	Standard	2-position single/3-position		0.15 to 0.7				
pressure		2-position double	0.1 to 0.7					
range	High- pressure	2-position single/3-position		0.15 to 1.0		S		
(MPa)	type	2-position double		0.1 to 1.0		0		
Ambient ar	ng)							
Max. opera		2-position single/double	10	10	5	S		
frequency (	(Hz)	3-position	_	3	3	E		
Manual ove	erride		Non-locking push type Push-turn locking slotted type					
Pilot exhau			Push-turn locking lever type Individual exhaust, Main/Pilot valve common exhaust (Except VF1000)					
Lubrication	-		Not required					
Mounting o			Unrestricted					
	ration res	istance (m/s <sup>2</sup> ) Note)		300/50		S		
Enclosure				roof (IP65* for D				
Note) Impact re	esistance:	No malfunction occurre angles to the main valve				S		
Vibration	n resistance	every once for each cond No malfunction occurred performed at both energy	d in a one-sweep te	st between 45 and		V		
· Deced on IE(	C 60500 W	the right angles to the ma then using IP65, select the r	ain valve and armat	ure. (Values at the in		V		

#### **Solenoid Specifications**

			-			
			Grommet (G), (H)	DIN terminal (D)		
Electrical entry	,		L-type plug connector (L)	DIN (EN175301-803) terminal (Y)		
Liectrical entry			M-type plug connector (M)	Conduit terminal (T)		
			G, H, L, M	D, Y, T		
Coil rated		DC	24,	12		
voltage (V)		AC (50/60 Hz)	24, 100, 110,	200, 220, 240		
Allowable volta	nge f	luctuation	±10% of rat	ed voltage*		
Power con-		Standard	1.5 (With light: 1.55)	1.5 (With light: 1.75)		
sumption (W)	DC	With power	0.55 Note) (With light only)	0.75 Note) (With light only)		
sumption (W)		saving circuit	[Starting 1.55 Holding 0.55]	[Starting 1.75 Holding 0.75]		
		24 V	1.5 (With light: 1.55)	1.5 (With light: 1.75)		
		100 V				
Apparent	AC	110 V [115 V]				
power (VA)*	AC	200 V	1.55 (With light: 1.65)	1.55 (With light: 1.7)		
		220 V [230 V]				
		240 V				
Surge voltage	supp	ressor	Diode (Non-polar type: Varistor)			
Indicator light			LED (Neon light is used for AC mode of D, Y, T.)			
It is in common between 110 VAC and 115 VAC, and between 220 VAC and 220 VAC						

\* It is in common between 110 VAC and 115 VAC, and between 220 VAC and 230 VAC

\* Allowable voltage fluctuation is -15% to +5% of the rated voltage for 115 VAC or 230 VAC. \* Since voltage drops due to the internal circuit in S, Z, T types (with power saving circuit), the allowable voltage fluctuation should be within the following range.

24 VDC: -7% to +10% 12 VDC: -4% to +10%

Note) Refer to page 858 for details.

#### **Response Time**

Nade 1 Orde

Symbol

X500

X600

			Descent	0		Response time (m:	s) (at 0.5 MPa)		
Series	Type of actuation		Pressure	Operating pressure	Without light/surge	With light/surge voltage suppressor		AC	
			specifications	range (MPa)	voltage suppressor	S, Z type	R, U type	AC	
		Single	Standard	0.15 to 0.7	20	45	23	45	
VF1000	2-position	Double	Standard	0.1 to 0.7	12	12	12	12	
VFIUUU	2-position	Single	High-pressure	0.15 to 1.0	23	48	26	48	
		Double	type	0.1 to 1.0	15	15	15	15	
	0 position	Single		0.15 to 0.7	20	45	23	45	
	2-position	Double	Standard	0.1 to 0.7	12	12	12	12	
VF3000	3-position			0.15 to 0.7	30	55	33	55	
VF3000	2-position	Single	High-pressure type	0.15 to 1.0	23	48	26	48	
		Double		0.1 to 1.0	15	15	15	15	
	3-p	3-position		0.15 to 1.0	33	58	36	58	
	2-position	Single		0.15 to 0.7	30	55	33	55	
	2-position	Double	Standard	0.1 to 0.7	15	15	15	15	
VF5000	3-p	osition		0.15 to 0.7	50	75	53	75	
VI-3000	2-position	Single		0.15 to 1.0	33	58	36	58	
	2-position	Double	High-pressure	0.1 to 1.0	18	18	18	18	
	3-p	osition	type	0.15 to 1.0	53	78	56	78	

Note) Based on dynamic performance test, JIS B 8375-1981. (Coil temperature: 20°C, at rated voltage)

S0700

VO

VQ4

VQ5 VOC VQC4 VQZ SQ VFS

VFR


VQ7

#### Flow-rate Characteristics/Weight

			Port	size		Flow	rate char	acteristics	Note 1)			( ) Note ()
	-	e	1, 4, 2		1 →	4/2 (P →	A/B)	$4/2 \rightarrow 5/$	/3 (A/B →	EA/EB)	Weight	(g) Note 2)
Valve model	1)	Type of actuation		5, 3 (EA, EB)	C [dm <sup>3</sup> / (s·bar)]	b	Cv	C [dm <sup>3</sup> / (s·bar)]	b	Cv	Grommet	DIN terminal
	2-	Single	ME	x 0.8	0.49	0.40	0.13	0.52	0.35	0.13	140	176
VF1□20-M5	position	Double		x U.O	0.49	0.40	0.13	0.52	0.35	0.13	200	272
	2-	Single	1/8	M5 x 0.8	0.76	0.22	0.17	0.53	0.28	0.13	136	172
VF1□20-01	position	Double	1/0	IVI5 X U.6	0.76	0.22	0.17	0.53	0.28	0.13	196	268
	2-	Single			3.0	0.38	0.78	2.8	0.30	0.67	182	218
	position	Double	]		3.0	0.38	0.78	2.8	0.30	0.67	243	315
		Closed center	]		2.4	0.31	0.64	1.8	0.37	0.46	260	332
VF3⊡30-01	3- position	Exhaust center	1.	/8	2.6	0.37	0.70	3.0 [2.5]	0.32 [0.28]	0.76 [0.62]	260	332
	position	Pressure center			3.0 [1.4]	0.42 [0.44]	0.83 [0.39]	2.4	0.27	0.59	260	332
	2-	Single			4.0	0.36	1.0	3.1	0.32	0.75	178	214
	position	Double	1		4.0	0.36	1.0	3.1	0.32	0.75	239	311
		Closed center	]		2.4	0.45	0.68	1.9	0.37	0.47	256	328
VF3⊡30-02	3- position	Exhaust center	1/4	1/8	3.0	0.42	0.82	3.1 [2.7]	0.36 [0.29]	0.79 [0.66]	256	328
	position	Pressure center			5.5 [1.4]	0.37 [0.50]	1.4 [0.40]	2.6	0.32	0.64	256	328
	2-	Single			7.1	0.46	1.9	7.7	0.51	2.2	313	349
	position	Double			7.1	0.46	1.9	7.7	0.51	2.2	368	440
		Closed center			6.7	0.46	1.8	6.6	0.41	1.8	406	478
VF5□20-02	3- position	Exhaust center	1.	/4	7.1	0.42	1.9	8.0 [7.4]	0.45 [0.47]	2.2 [2.1]	406	478
		Pressure center			6.8 [2.7]	0.51 [0.50]	2.0 [0.78]	5.7	0.37	1.4	406	478
	2-	Single			8.8	0.44	2.4	10.0	0.49	2.9	299	335
	position	Double			8.8	0.44	2.4	10.0	0.49	2.9	354	426
		Closed center			7.5	0.43	2.0	7.5	0.38	1.9	391	463
VF5□20-03	3- position	Exhaust center	3/8		8.3	0.40	2.2	10.0 [8.7]	0.48 [0.46]	3.0 [2.4]	391	463
		Pressure center			9.2 [3.0]	0.50 [0.49]	2.6 [0.85]	6.1	0.35	1.6	391	463

Note 1) [ ]: Normal position Note 2) Values without bracket

#### **Construction: Body Ported**



No.	Description	Material	Note							
1	Body	Aluminum die-casted	White							
2	Adapter plate	Resin	Gray							
3	End plate	Resin (VF313□-F VF1120-F : Aluminum die-casted)	White							
4	Piston	Resin								
5	Spool valve	Aluminum, HNBR								

#### Spring **Replacement Parts**

6

No.	Description	Part no.	Note
7	Pilot valve assembly	Refer to "How to Order Pilot Valve Assembly" on page 812.	Built-in strainer

Stainless steel


#### Bracket Assembly Part No.

Description	Part no.
Bracket (for VF1000 double)	DXT144-8-1A (With 2 mounting screws)

#### How to Order Pilot Valve Assembly (With a gasket and two mounting screws)

#### \land Caution

When only the pilot valve assembly is replaced, it is not possible to change from V211 (Grommet or L/M-type) to V212 (DIN or Conduit type), or vice versa.



### A Caution


For V212 (DIN or Conduit type), the coil specifications and voltage (including light/surge voltage suppressor) cannot be changed by replacing the pilot valve assembly.

**SMC** 

### \land Caution

Tightening torque of the pilot valve assembly mounting screw M2.5: 0.32 N·m 812

#### Dimensions: Series VF1000/Body Ported



0

′⊕

@SMC


55.5

۲


[ ]: Without indicator light Unless otherwise indicated, dimensions are the same as Grommet (G).

6


#### **Dimensions: Series VF1000/Body Ported**



#### L-type plug connector (L): VF1220-





Unless otherwise indicated, dimensions are the same as Grommet (G)





Unless otherwise indicated, dimensions are the sa me as Grommet (G)


#### Grommet (G) (H): VF1220-04 Gine 1-01













Unless otherwise indicated, dimensions are the same as Grommet (G).

#### Conduit terminal (T): VF1220-

**SMC** 



#### **Dimensions: Series VF3000/Body Ported**



@SMC


Unless otherwise indicated, dimensions are the same as Grommet (G)

[]: Without indicator light Unless otherwise indicated, dimensions are the same as Grommet (G).


#### **Dimensions: Series VF3000/Body Ported**

#### 2-position double

Grommet (G) (H): VF3230-





#### L-type plug connector (L): VF3230-□L□□1-<sup>01</sup><sub>02</sub>□




Unless otherwise indicated, dimensions are the same as Grommet (G).


#### M-type plug connector (M): VF3230-






Grommet (G) (H) DC without light/surge voltage suppressor









Unless otherwise indicated, dimensions are the same as Grommet (G).

#### Conduit terminal (T): VF3230-



**SMC** 


#### **Dimensions: Series VF3000/Body Ported**




@SMC

#### **Dimensions: Series VF5000/Body Ported**

#### 2-position single




#### L-type plug connector (L): VF5120-□L□□1-02




Unless otherwise indicated, dimensions are the same as Grommet (G)


#### M-type plug connector (M): VF5120-DMDD1-02




Unless otherwise indicated, dimensions are the same as Grommet (G),

#### Grommet (G) (H) DC without light/surge voltage suppressor









Unless otherwise indicated, dimensions are the same as Grommet (G).

#### Conduit terminal (T): VF5120-



**SMC** 

#### **Dimensions: Series VF5000/Body Ported**



@SMC

Unless otherwise indicated, dimensions are the same as Grommet (G).


Φ

Φ


[]: Without indicator light Unless otherwise indicated, dimensions are the same as Grommet (G).

0 0

#### **Dimensions: Series VF5000/Body Ported**




### L-type plug connector (L): VF5<sup>3</sup>/<sub>4</sub>20-□L□□1-<sup>02</sup><sub>03</sub>




Unless otherwise indicated, dimensions are the same as Grommet (G).

M-type plug connector (M): VF5 $\frac{3}{4}$ 20- $\square$ M $\square$  $\square$ 1- $\frac{02}{03}$  $\square$ 




Unless otherwise indicated, dimensions are the same as Grommet (G), 820

DIN terminal (D) (Y): VF5<sup>3</sup>/<sub>4</sub>20-□<sup>D</sup>/<sub>7</sub>□□1-<sup>02</sup>/<sub>03</sub>□



Unless otherwise indicated, dimensions are the same as Grommet (G).

### Conduit terminal (T): VF5<sup>3</sup>/<sub>4</sub>20-□T□□1-<sup>02</sup><sub>03</sub>□



**SMC** 

Series VF1000/3000/5000 Made to Order


Please contact SMC for detailed dimensions, specifications, and lead times.




SY

#### 1 Body Ported Pilot Exhaust Port with Piping Thread (M3) Specification


In this specification, piping to the pilot exhaust port (PE port) is available when the valve is used in an environment where the SJ exhaust from the pilot valve is not allowable, or intrusion of ambient dust should be prevented. Combination with low wattage specification is not possible.



For AC type valve, use this specification when the pilot valve is not recovered even though valve power supply is turned OFF at the equipment using output unit with large leakage voltage over 8% of the rated voltage (TRIAC output such as PLC or SSR, etc.). Combination with low wattage specification is not possible.



How to Order Valve



Pilot Operated 5 Port Solenoid Valve Base Mounted/Single Unit Series VF3000/5000

#### Specifications

	N	lodel	VF3000	VF5000	
Fluid			Air		
Operating Standard pressure		2-position single/3-position	0.15 to 0.7		
		2-position double	0.1 to	o 0.7	
range	High- pressure	2-position single/3-position	0.151	to 1.0	
(MPa)	type	2-position double	0.1 to	o 1.0	
Ambient a	nd fluid te	mperature (°C)	-10 to 50 (N	No freezing)	
Max. operation of the second s		2-position single/double	10	5	
frequency	requency (Hz) 3-position		3	3	
Manual override			Non-locking push type Push-turn locking slotted type Push-turn locking lever type		
Pilot exha	ust type		Individual exhaust, Main/ Pilot valve common exhaust	Pilot valve base exhaust	
Lubricatio			Not required		
Mounting			Unres		
Impact/Vit	pration res	sistance (m/s <sup>2</sup> ) Note)	300		
Enclosure			Dustproof (IP6	i5* for D, Y, T)	
Note) Impact resistance: No malfunction occurred when it is tested in the axial direction and at the right angles to the main valve and armature in both energized and de-nergized states every once for each condition. (Values at the initial period)					
Vibratio	on resistanc	performed at both energi	in a one-sweep test between zed and de-energized states in valve and armature. (Value	in the axial direction and a	

\* Based on IEC 60529. When using IP65, select the main/pilot valve common exhaust type or pilot valve base exhaust type.

#### Solenoid Specifications

Electrical entry			Grommet (G), (H) L-type plug connector (L) M-type plug connector (M)	DIN terminal (D) DIN (EN175301-803) terminal (Y) Conduit terminal (T)	
			G, H, L, M	D, Y, T	
Coil rated		DC	24,	12	
voltage (V)		AC (50/60 Hz)	24, 100, 110,	200, 220, 240	
Allowable voltage fluctuation			±10% of rat	ed voltage*	
Demanage		Standard	1.5 (With light: 1.55)	1.5 (With light: 1.75)	
Power con- sumption (W)	DC	With power	0.55 Note) (With light only)	0.75 Note) (With light only)	
Sumption (II)		saving circuit	[Starting 1.55 Holding 0.55]	[Starting 1.75 Holding 0.75]	
		24 V	1.5 (With light: 1.55)	1.5 (With light: 1.75)	
		100 V			
Apparent	AC	110 V [115 V]			
power (VA)*		200 V	1.55 (With light: 1.65)	1.55 (With light: 1.7)	
		220 V [230 V]			
		240 V			
Surge voltage suppressor Diode (Non-polar type: Varistor					
Indicator light			LED (Neon light is used for AC mode of D, Y, T.)		
It is in common b	etwe	en 110 VAC and 1	15 VAC, and between 220 VAC and	d 230 VAC.	

\* Allowable voltage fluctuation is -15% to +5% of the rated voltage for 115 VAC or 230 VAC.

Since voltage drops due to the internal circuit in S, Z, T types (with power saving circuit), the allowable voltage fluctuation should be within the following range.
 24 VDC: -7% to +10%
 24 VDC: -7% to +10%


Note) Refer to page 858 for details.

#### **Response Time**

		Type of actuation		Operating pressure	Response time (ms) (at 0.5 MPa)				
Series	Type of			range (MPa)	Without light/surge	With light/surge v	oltage suppressor	AC	
			specifications	Taliye (IVIFa)	voltage suppressor	S, Z type	R, U type	AC	
		Single	Standard	0.15 to 0.7	20	45	23	45	
VF1000	O nonition	Double	Standard	0.1 to 0.7	12	12	12	12	
VF1000	2-position	Single	High-pressure	0.15 to 1.0	23	48	26	48	
		Double	type	0.1 to 1.0	15	15	15	15	
	2-position	Single		0.15 to 0.7	20	45	23	45	
	2-position	Double	Standard	0.1 to 0.7	12	12	12	12	
VF3000	3-pc	3-position		0.15 to 0.7	30	55	33	55	
VF3000	2-position	Single	High-pressure type	0.15 to 1.0	23	48	26	48	
		Double		0.1 to 1.0	15	15	15	15	
	3-position		,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	0.15 to 1.0	33	58	36	58	
	2-position	Single		0.15 to 0.7	30	55	33	55	
	2-position	Double	Standard	0.1 to 0.7	15	15	15	15	
VF5000	3-pc	osition		0.15 to 0.7	50	75	53	75	
VI-3000	O position	Single		0.15 to 1.0	33	58	36	58	
	2-position	Double	High-pressure	0.1 to 1.0	18	18	18	18	
	3-pc	osition	type	0.15 to 1.0	53	78	56	78	

Note) Based on dynamic performance test, JIS B 8375-1981. (Coil temperature: 20°C, at rated voltage)





Series VE5000

### Series VF3000/5000


#### Flow-rate Characteristics/Weight

					Flow-	rate chara	acteristics	Note 1)			N-1-0
				1 →	4/2 (P →	A/B)	$4/2 \rightarrow 5/2$	/3 (A/B →	EA/EB)	Weight (g) Note 2)	
Valve model	Type of actuation		Port size	C [dm³/ (s·bar)]	b	Cv	C [dm <sup>3</sup> / (s·bar)]	b	Cv	Grommet	DIN terminal
VF3□40-02	2-	Single		2.8	0.14	0.64	2.5	0.18	0.57	344 (192)	380 (228)
	position	Double		2.8	0.14	0.64	2.5	0.18	0.57	405 (252)	477 (324)
		Closed center		2.1	0.22	0.49	1.6	0.26	0.41	422 (270)	494 (342)
	3- position	Exhaust center	1/4	2.3	0.21	0.53	2.8 [2.1]	0.23 [0.26]	0.66 [0.50]	422 (270)	494 (342)
		Pressure center		2.9 [1.1]	0.16 [0.45]	0.67 [0.32]	2.1	0.23	0.49	422 (270)	494 (342)
	2-	Single		3.1	0.24	0.76	2.6	0.23	0.62	327 (192)	363 (228)
	position	Double		3.1	0.24	0.76	2.6	0.23	0.62	388 (252)	460 (324)
	3- position	Closed center	3/8	2.2	0.33	0.57	1.6	0.34	0.40	405 (270)	477 (342)
VF3⊟40-03		Exhaust center		2.6	0.27	0.61	2.8 [2.3]	0.30 [0.28]	0.68 [0.55]	405 (270)	477 (342)
		Pressure center		3.4 [1.3]	0.29 [0.48]	0.80 [0.38]	2.2	0.31	0.52	405 (270)	477 (342)
	2-	Single	1/4	7.3	0.49	2.1	7.3	0.50	2.0	486 (297)	522 (333)
	position	Double		7.3	0.49	2.1	7.3	0.50	2.0	541 (352)	613 (424)
	3- position	Closed center		6.6	0.35	1.7	6.3	0.31	1.6	578 (390)	650 (462)
VF5□44-02		Exhaust center		7.4	0.33	1.9	8.1 [7.4]	0.35 [0.34]	2.1 [1.9]	578 (390)	650 (462)
		Pressure center		8.0 [2.9]	0.35 [0.48]	2.1 [0.85]	5.6	0.31	1.5	578 (390)	650 (462)
	2-	Single		8.4	0.34	2.2	8.9	0.29	2.3	473 (297)	509 (333)
	position	Double		8.4	0.34	2.2	8.9	0.29	2.3	529 (352)	601 (424)
		Closed center		7.3	0.34	2.0	7.1	0.28	1.8	566 (390)	638 (462)
VF5□44-03	3- position	Exhaust center	3/8	8.1	0.27	2.0	14.0 [8.3]	0.26 [0.31]	3.4 [2.2]	566 (390)	638 (462)
		Pressure center		8.1 [2.5]	0.33 [0.48]	2.0 [0.74]	5.7	0.31	1.4	566 (390)	638 (462)
	2-	Single		9.4	0.43	2.7	12.0	0.32	3.0	545 (297)	581 (333)
	position	Double		9.4	0.43	2.7	12.0	0.32	3.0	600 (352)	672 (424)
		Closed center		7.1	0.41	2.1	7.4	0.32	2.0	638 (390)	710 (462)
VF5□44-04	3- position	Exhaust center	1/2	8.6	0.39	2.4	13.0 [8.9]	0.21 [0.40]	3.1 [2.5]	638 (390)	710 (462)
		Pressure center		11.0 [2.6]	0.18 [0.47]	2.6 [0.78]	6.1	0.35	1.6	638 (390)	710 (462)

Note 1) [ ]: Normal position Note 2) ( ): Values without sub-plate

#### Pilot Operated 5 Port Solenoid Valve Base Mounted/Single Unit Series VF3000/5000

#### **Construction: Base Mounted**



No.	Description	Part	t no.	Nete
INO.	Description	VF3000	VF5000	Note
7	Pilot valve assembly	Refer to "How to Order Pilot V	Built-in strainer	
8	Gasket	DXT031-30-11	DXT156-9-8	HNBR
9	Sub-plate	1/4: VF3000-71-1□ 3/8: VF3000-71-2□	1/4: VF5000-71-1□ 3/8: VF5000-71-2□ 1/2: VF5000-71-3□	Aluminum die-casted
-	Round head combination screw (1 pc.)	DXT031-44-1 (M4 x 39.5, With spring washer)	—	For mounting valve
-	Hexagon socket head cap screw (1 pc.)	_	AXT620-32-1 (M4 x 48, With spring washer)	For mounting valve

**SMC** 




825

### Series **VF3000/5000**

#### How to Order Pilot Valve Assembly (With a gasket and two mounting screws)

#### \land Caution

When only the pilot valve assembly is replaced, it is not possible to change from V211 (Grommet or L/M-type) to V212 (DIN or Conduit type), or vice versa.



### ▲ Caution


For V212 (DIN or Conduit type), the coil specifications and voltage (including light/surge voltage suppressor) cannot be changed by replacing the pilot valve assembly.

**SMC** 


### \land Caution

Tightening torque of the pilot valve assembly mounting screw M2.5: 0.32 N·m 826

#### **Dimensions: Series VF3000/Base Mounted**



@SMC



Unless otherwise indicated, dimensions are the same as Grommet (G).

Applicable cable O.D. e4.5 to e7 Figure 10 Figure 10

132.2

[ ]: Without indicator light Unless otherwise indicated, dimensions are the same as Grommet (G).

Max. 10

SJ

SY Sy Sv

SYJ

SZ

VF

VP4

S0700

VO

V04

V05

VOC

VQC4 VOZ

SO

VFS

VFR


V07

### Series VF3000/5000

#### **Dimensions: Series VF3000/Base Mounted**


#### 2-position double






81

L-type plug connector (L): VF3240- L III 1-02




Unless otherwise indicated, dimensions are the same as Grommet (G).


#### M-type plug connector (M): VF3240-DMDD1-02D



Unless otherwise indicated, dimensions are the same as Grommet (G)


Grommet (G) (H) DC without light/surge voltage suppressor





Unless otherwise indicated, dimensions are the same as Grommet (G).


#### Conduit terminal (T): VF3240-






**SMC** 

#### **Dimensions: Series VF3000/Base Mounted**




### Series VF3000/5000

#### **Dimensions: Series VF5000/Base Mounted**




#### **Dimensions: Series VF5000/Base Mounted**




### Series VF3000/5000

#### Dimensions: Series VF5000/Base Mounted



# Low Wattage Specification Series VF1000/3000 ( Single Unit

Body Ported Base Mounted



### Series VF1000/3000



Mo	del	VF1000	VF3000		
Fluid		Air			
Internal pilot operating 2-position single/3-position		0.15	to 0.7		
pressure range (MPa)	2-position double	0.1 to 0.7			
Ambient and fluid ter	nperature (°C)	-10 to 50 (N	lo freezing)		
Max. operating	2-position single/double	5	5		
frequency (Hz)	3-position	3	3		
		Non-locking push type			
Manual override		Push-turn locking slotted type			
		Push-turn locking lever type			
Pilot exhaust type		Main/Pilot valve common exhaust			
Lubrication		Not required			
Mounting orientation		Unrestricted			
Impact/Vibration resi	stance (m/s <sup>2</sup> ) Note)	150/30			
Enclosure		Dustproof (IP65* for DIN terminal)			
Beend on IEC 60500					

Based on IEC 60529.

Specifications

Note) Impact resistance:

ed on IEC 60529. Impact resistance: No malfunction occurred when it is tested in the axial direction and at the right angles to the main valve and armature in both energized and de-energized states every once for each condition. (Values at the initial period) Vibration resistance: No malfunction occurred in a one-sweep test between 45 and 2000 Hz. Test was performed at both energized and de-energized states in the axial direction and at the right angles to the main valve and armature. (Values at the initial period)

#### **Solenoid Specifications**

Electrical entry			Grommet (G), (H) L-type plug connector (L) M-type plug connector (M)													
			G, H, L, M	D, Y												
Coil rated		DC	24,	12												
voltage (V)		AC (50/60 Hz)	100, 110,	200, 220												
Allowable voltage fluctuation			±10% of rated voltage*													
Power consumption (W)	DC	Standard	0.35 {With light: 0.4 (With light of DIN terminal: 0.45)}													
	AC	100 V	0.78 (With light: 0.81)	0.78 (With light: 0.87)												
Apparent		110 V [115 V]	0.86 (With light: 0.89) [0.94 (With light: 0.97)]	0.86 (With light: 0.97) [0.94 (With light: 1.07)]												
power (VA)*		AC	AC	AC	AC	AC	AC	AC	AC	AC	AC	AC	AC	AC	200 V	1.18 (With light: 1.22)
		220 V [230 V]	1.30 (With light: 1.34) [1.42 (With light: 1.46)]	1.27 (With light: 1.46) [1.39 (With light: 1.60)]												
Surge voltage suppressor			Diode (DIN terminal, Non-polar type: Varistor)													
Indicator light			LED (Neon light is used for AC mode of DIN terminal.)													

\* It is in common between 110 VAC and 115 VAC, and between 220 VAC and 230 VAC.


 Allowable voltage fluctuation is -15% to +5% of the rated voltage for 115 VAC or 230 VAC.
 Since voltage drops due to the internal circuit in S and Z types, the allowable voltage fluctuation should be within the following range.

24 VDC: -7% to +10% 12 VDC: -4% to +10%

#### **Response Time**

		Response time (ms) (at 0.5 MPa)				
Series	Type of actuation		With light/surge voltage suppressor		AC	
		voltage suppressor	S, Z type	R, U type	AC	
VF1000	2-position single	45	55	45	45	
VFI000	2-position double	12	12	12	12	
	2-position single	55	63	55	50	
VF3000	2-position double	14	14	14	16	
	3-position	100	100	90	90	

#### Low Wattage Specification Body Ported/Base Mounted/Single Unit Series VF1000/3000



37.7

(AC)

**SMC** 

\_30

47.5

(AC)


\_30

835


### Series VF1000/3000


#### Dimensions

#### VF3000




L-type plug connector (L)






M-type plug connector (M)

DIN terminal (D) (Y)



# **Pilot Operated 5 Port Solenoid Valve** Series VF1000/3000/5000 Manifold

**Body Ported** 



∕∂SMC

Refer to page 857 for details on the DIN (EN175301-803) terminal.
 Note 1) When using IP65, select the main/pilot valve common exhaust type

Note 2) With the same specifications as the DC type, all electrical entries for the 24 VAC type are CE marking compliant.

page 858 for details.


#### **Manifold Specifications**

Series	VF1	000	VF3000	VF5	000
Manifold base model	VV5F1-30 4(A), 2(B) port 1/8 1/8 1/9 port 1/8 5/3(R) port 1/8 5/3(R) port 1/8	VV5F1-31 4(A), 2(B) port 1/8 (EA), 3(EB) port M5 x 0.8 1(P) port 1/8	VV5F3-30 4(A), 2(B) port 1/8, 1/4 1/4 5(R), 3(R) port 1/4	7 <b>VV5F5-20</b> 4(A), 2(B) port 1/4, 3/8 1/4, 3/8	VV5F5-21 1(P) port 1/2 5(R), 3(R) port 1/2 P) port 3/8
EXH port type	Common EXH	Individual EXH	Common EXH	Common EXH	Common EXH
Applicable valve model	VF1⊑ VF1□		VF3⊟30 VF3⊟33	VF5 VF5	
Applicable stations	2 to 20	stations	2 to 20 stations	2 to 10 stations	2 to 15 stations
Manifold base Weight: W [g] Stations: n	W = 29n + 21	W = 51n + 35	W = 63n + 64	W = 97n + 80	W = 139n + 550

Note) Supply pressure to 1(P) ports and exhaust pressure from R ports on both sides for 10 stations or more (5 stations or more for the VF5000).

#### How to Order Manifold Assembly






 Under the manifold base part number, state the valves to be mounted in order from the 1st station as shown in the figure above. If the arrangement becomes complicated, specify on the manifold specification sheet.



# Pilot Operated 5 Port Solenoid Valve Body Ported/Manifold Series VF1000/3000/5000

#### **Manifold Options**




1/4

Ν т

NPTF

# Series VF1000/3000/5000

#### **Dimensions: Series VF1000**




(Indicator light) 65 42 20

#### I · Dimensions

L: Dimensions n: Stations													
7/	2	3	4	5	6	7	8	9	10	11	12	13	14
L1	74.5	102	129.5	157	184.5	212	239.5	267	294.5	322	349.5	377	404.5
L2	64.5	92	119.5	147	174.5	202	229.5	257	284.5	312	339.5	367	394.5


$\sum$	15	16	17	18	19	20
L1	432	459.5	487	514.5	542	569.5
L2	422	449.5	477	504.5	532	559.5

#### M-type plug connector (M)




Unless otherwise indicated, dimensions are the same as Grommet (G).

DIN terminal (D) (Y)




Unless otherwise indicated, dimensions are the same as Grommet (G)

L-type plug connector (L)



Unless otherwise indicated, dimensions are the same as Grommet (G).

#### Conduit terminal (T)




[ ]: Without indicator light

Unless otherwise indicated, dimensions are the same as Grommet (G)







Unless otherwise indicated, dimensions are the same as Grommet (G).

Unless otherwise indicated, dimensions are the same as Grommet (G).

1: Without indicator light


Grommet (G).


Unless otherwise indicated, dimensions are the same as


# Series VF1000/3000/5000

#### **Dimensions: Series VF3000**


Type 30/VV5F3-30-001-00: Common exhaust Grommet (G) (H)








L-type plug connector (L)



Unless otherw indicated, dimensions are the same as Grommet (G).




#### L: Dimensions

·	h: Stations												
L n	2	3	4	5	6	7	8	9	10	11	12	13	14
L1	83.5	111	138.5	166	193.5	221	248.5	276	303.5	331	358.5	386	413.5
L2	71.5	99	126.5	154	181.5	209	236.5	264	291.5	319	346.5	374	401.5

(Indicator light)


$\sum_{i=1}^{n}$	15	16	17	18	19	20
L1	441	468.5	496	523.5	551	578.5
L2	429	456.5	484	511.5	539	566.5

#### M-type plug connector (M)




Unless otherwise indicated, dimensions are the same as Grommet (G).

## DIN terminal (D) (Y)



Conduit terminal (T)




]: Without indicator light

Unless otherwise indicated, dimensions are the same as Grommet (G)


842




Grommet (G)




## Type 30/VV5F3-30-001-0: When the individual EXH spacer (VF3000-75-1A) is mounted.





Unless otherwise indicated, dimensions are the same as Grommet (G).

Unless otherwise indicated, dimensions are the same as Grommet (G).




1: Without indicator light


Unless otherwise indicated, dimensions are the same as Grommet (G).

@SMC


# Series VF1000/3000/5000

#### **Dimensions: Series VF5000**






(Station n) ······(Station 1)



# L-type plug connector (L)



en ports)

(30.4) (Distance


47.3

Unless otherwise indicated, dimensions are the same as Grommet (G)




L. D	L. Dimensions n: Stations												
$\sim$	2	3	4	5	6	7	8	9	10				
L1	93	126	159	192	225	258	291	324	357				
L2	80	113	146	179	212	245	278	311	344				

#### M-type plug connector (M)



Unless otherwise indicated, dimensions are the same as Grommet (G).


## DIN terminal (D) (Y)



Unless otherwise indicated, dimensions are the same as Grommet (G)




Conduit terminal (T)




[ ]: Without indicator light Unless otherwise indicated, dimensions are the same as Grommet (G).






## Type 20/VV5F5-20-


	II. Stations												
$\sim$	2	3	4	5	6	7	8	9	10				
L1	93	126	159	192	225	258	291	324	357				
L2	80	113	146	179	212	245	278	311	344				



Unless otherwise indicated, dimensions are the same as Grommet (G).



indicated, dimensions are the same as Unless otherwise Grommet (G).



]: Without indicator light


Unless otherwise indicated, dimensions are the same as Grommet (G).

SMC


# Series VF1000/3000/5000

#### **Dimensions: Series VF5000**

Type 21/VV5F5-21-001-0: Common exhaust Grommet (G)




(Station n) ····· (Station 1)



#### L: Dimensions


·	h: Stations													
$\sim$	2	3	4	5	6	7	8	9	10	11	12	13	14	15
L1	163	196	229	262	295	328	361	394	427	460	493	526	559	592
L2	128	161	194	227	260	293	326	359	392	425	458	491	524	557

#### M-type plug connector (M)




Unless otherwise indicated, dimensions are the same as Grommet (G).


## DIN terminal (D) (Y)




indicated, dimensions are the same as Unless otherwise Grommet (G). ₿SMC



1/2




L-type plug connector (L)




Unless otherwi Grommet (G).

Conduit terminal (T)




ſ ]: Without indicator light

Unless otherwise indicated, dimensions are the same as Grommet (G).




## Type 21/VV5F5-21-01-0: When the individual EXH spacer (VF5000-75-1A) is mounted.


$\sim$	2	3	4	5	6	7	8	9	10	11	12	13	14	15
Li	163	196	229	262	295	328	361	394	427	460	493	526	559	592
L2	128	161	194	227	260	293	326	359	392	425	458	491	524	557




Unless otherwise indicated, dimensions are the same as Grommet (G).



e indicated, dimensions are the same as Unless otherv Grommet (G).






]: Without indicator light

Unless otherwise indicated, dimensions are the same as Grommet (G).






Note 1) When using IP65, select the main/pilot valve common exhaust or pilot valve base exhaust type

Note 2) With the same specifications as the DC type, all electrical entries for the 24 VAC type are CE marking compliant.

@ SMC


#### Pilot Operated 5 Port Solenoid Valve Base Mounted/Manifold Series VF3000/5000


#### **Manifold Specifications**



## Series VF3000/5000


## **Manifold Options**






Series	Blanking plate assembly part no.
VF3000	DXT031-38-5A
VF5000	VF5000-70-2A

#### Individual EXH spacer assembly



Series	Valve mounting screw (1 pc.)	Gasket
VF3000	Round head combination screw DXT031-44-1 (M4 x 39.5, With spring washer)	DXT031-30-11
VF5000	Hexagon socket head cap screw AXT620-32-1 (M4 x 48, With spring washer)	DXT156-9-8



# VF3000-75-2A

Series										
Symbol	Series	Port size								
3	VF3000	1/8								
5	VF5000	1/4								

Thread type								
Nil	Rc							
F	G							
Ν	NPT							
т	NPTF							

## ▲ Caution

Tightening Torque for Mounting Screw

M4: 1.4 N·m

## ▲Warning

When mounting a valve or spacer on the manifold base or sub-plate, etc., the mounting orientation is already decided. If mounted in a wrong direction, the equipment to be connected may result in a malfunction. Refer to the dimensions for mounting.

35.6

Approx. 300

Grommet (G)

(Lead wire length)

α

57

œ

45.8


72.9

Œ

⊕

86.5

Unless otherwise indicated, dimensions are the same as



ø4.5 to ø7 Unless otherwise indicated, dimensions are the same as Grommet (G)

163.6

9

Иах.

81.8

SMC

Pa9

Applicable cable O.D.

106.5

115.5

68.4

2' Applicable

٨ax. ø4.5 to ø7

Grommet (G).

84.2

cable O.D

[ ]: Without indicator light

-0

Ð

-0

Ð

(Indicator light)

Unless otherwise indicated, dimensions are the same as


Pg9

109.7 [99.7]


119.7 [109.7]

# Series **VF3000/5000**

#### **Dimensions: Series VF3000**




#### M-type plug connector (M)




Unless otherwise indicated, dimensions are the same as Grommet (G).





Unless otherwise indicated, dimensions are the same as Grommet (G).

Conduit terminal (T)




[]: Without indicator light

Unless otherwise indicated, dimensions are the same as Grommet (G).



Grommet (G).




Unless otherwise indicated, dimensions are the same as Grommet (G)


@SMC


Grommet (G).

# Series VF3000/5000

#### **Dimensions: Series VF5000**









Unless otherwise indicated, dimensions are the same as Grommet (G)

#### DIN terminal (D) (Y)



Unless otherwise indicated, dimensions are the same as Grommet (G). ∕⊘SMC

Conduit terminal (T)



[]: Without indicator light

Unless otherwise indicated, dimensions are the same as Grommet (G)



Be sure to read before handling.

Refer to front matter 53 for Safety Instructions, pages 3 to 8 for 3/4/5 Port Solenoid Valves Precautions.

#### Manual Override

## **M**Warning


Regardless of an electric signal for the solenoid valve, the manual override is used for switching the main valve. Connected actuator is started by manual operation. Use the manual override after confirming that there is no danger.

#### Non-locking push type



Push down on the manual override with a small screwdriver until it stops. Release the screwdriver and the manual override will return.


#### Push-turn locking slotted type



# Locked position

Push down on the manual override with a small flat head screwdriver until it stops. Turn it clockwise by 90° to lock it. Turn it counterclockwise to release it.

#### Push-turn locking lever type



After pushing down, turn in the direction of the arrow. If it is not turned, it can be operated the same way as the non-locking push type.

## **≜**Caution

When locking the manual override on the push-turn locking type (D or E type), be sure to push it down before turning.


Turning without first pushing it down can cause damage to the manual override and other trouble such as air leakage, etc. Do not apply excessive torque when turning the locking type manual override. (0.1 N·m)

#### How to Use L/M-Type Plug Connector

## **≜**Caution


#### 1. Connector attachment/detachment

- To attach a connector, hold the lever and connector unit between your fingers and insert straight onto the pins of the solenoid valve so that the lever's pawl is pushed into the groove and locks.
- To detach a connector, remove the pawl from the groove by pushing the lever downward with your thumb, and pull the connector straight out.



#### 2. Crimping lead wire and socket connection

Not necessary if ordering the lead wire pre-connected model. Strip 3.2 to 3.7 mm at the end of the lead wires, insert the ends of the core wires evenly into the sockets, and then crimp with a crimping tool. When this is done, take care that the coverings of the lead wires do not enter the core wire crimping area. (Please contact SMC for details on the crimping tool.)




#### 3. Socket with lead wire attachment/detachment

#### Attachment

Insert the sockets into the square holes of the connector (with +, – indication), and continue to push the sockets all the way in until they lock by hooking into the seats in the connector. (When they are pushed in, their hooks open and they are locked automatically.) Then, confirm that they are locked by pulling lightly on the lead wires.

#### Detachment

To detach a socket from a connector, pull out the lead wire while pressing the socket's hook with a stick having a thin tip (approx. 1 mm). If the socket will be used again, first spread the hook outward.






Be sure to read before handling.

Refer to front matter 53 for Safety Instructions, pages 3 to 8 for 3/4/5 Port Solenoid Valves Precautions.

#### Plug Connector Lead Wire Length

## **A**Caution

Plug connector lead wires have a standard length of 300 mm, however, the following lengths are also available.



Lead wire ler					
Nil	300 mm				
6	600 mm				
10	1000 mm				
15	1500 mm				
20	2000 mm				
25	2500 mm				
30	3000 mm				
50	5000 mm				

#### How to Order

Specify the connector assembly part number together with the part number for the plug connector type solenoid valve without connector.

(Example) Lead wire length: 2000 mm

DC	AC
VF3130-5LO1-02	VF3130-1LO1-02
V200-30-4A-20	V200-30-1A-20

#### How to Use DIN Terminal Connector

The DIN terminal with an IP65 (enclosure) is protected against dust and water, however, it must not be used in water.

# 

#### Connection


- 1) Loosen the set screw and pull the connector out of the solenoid valve terminal block.
- 2) After removing the set screw, insert a flat head screwdriver, etc. into the notch on the bottom of the terminal block and pry it open, separating the terminal block and the housing.
- Loosen the terminal screws on the terminal block, insert the core of the lead wire into the terminal, and attach securely with the terminal screws.

In addition, when using the DC mode type with a surge voltage suppressor (polar: S and Z types), connect wires corresponding to the polarity (+ or –) that is printed on the terminal block.

4) Secure the cord by fastening the ground nut.

In the case of connecting wires, select cabtire cords carefully because if those out of the specified range (ø4.5 to ø7) are used, it will not be able to satisfy IP65 (enclosure).

Tighten the ground nut and set screw within the specified range of torque.



\* Refer to page 857 for the DIN connector part no.

#### Changing the entry direction

After separating the terminal block and housing, the cord entry direction can be changed by attaching the housing in the opposite direction.

\* Make sure not to damage elements, etc., with the lead wires of the cord.

#### Precautions

Plug in and pull out the connector vertically without tilting to one side.

#### Applicable cable

Cable O.D.: ø4.5 to ø7 (Reference) 0.5 mm² to 1.5 mm², 2-core or 3-core, equivalent to JIS C 3306

#### Applicable crimped terminal

O terminal: R1.25-4M that is specified in JIS C 2805 Y terminal: 1.25-3L, which is released by JST Mfg. Co., Ltd. Stick terminal: Size 1.5 or shorter






Be sure to read before handling.

Refer to front matter 53 for Safety Instructions, pages 3 to 8 for 3/4/5 Port Solenoid Valves Precautions.


#### DIN (EN175301-803) Terminal

Y type DIN terminal corresponds to the DIN connector with terminal pitch 10 mm, which complies with EN175301-803B. Since the terminal pitch is different from the D type DIN connector, these two types are not interchangeable.



#### How to Order DIN Connector

## **A**Caution



DC (
Z) circuit diagram




LED: Light emitting diode D: Protective diode R: Resistor

AC (
Z) circuit diagram



NL: Neon light, R: Resistor





Note) The 24 VAC specification is the same as those in the DC (□U) circuit diagram.

#### How to Use Conduit Terminal

## **≜**Caution

#### Connection

- 1) Loosen the set screw and remove the terminal block cover from the terminal block.
- Loosen the terminal screws on the terminal block, insert the core of the lead wire or crimped terminal

into the terminal, and attach securely with the terminal screws.

In addition, when using the DC mode type with a surge voltage suppressor (polar: S and Z types), connect wires to terminal 1 and 2 corresponding to the polarity (+ or -) as shown on the right figure.



SV SYJ SZ VF

SJ

SY

SY


S0700

VO

Secure the cord by fastening the ground nut.

In the case of connecting wires, select cabtire cords carefully because if those out of the specified range (ø4.5 to ø7) are used, it will not be able to satisfy IP65 (enclosure).

Tighten the ground nut and set screw within the specified range of torque.



#### Applicable cable

Cable O.D.: ø4.5 to ø7

(Reference) 0.5  $\rm mm^2$  to 1.5  $\rm mm^2,$  2-core or 3-core, equivalent to JIS C 3306

#### Applicable crimped terminal

O terminal: Equivalent to R1.25-3 that is specified in JIS C 2805 Y terminal: Equivalent to 1.25-3, which is released by JST Mfg. Co., Ltd.

\* Use O terminal when a ground terminal is used.





Be sure to read before handling.

Refer to front matter 53 for Safety Instructions, pages 3 to 8 for 3/4/5 Port Solenoid Valves Precautions.


#### Light/Surge Voltage Suppressor

## **≜**Caution

#### <DC>


Polar type

With surge voltage suppressor (
S)



Polarity protection diode

Grommet or L/M-type plug connector
 With light/surge voltage suppressor (□Z)
 Polarity protection diode




 DIN or Conduit terminal With light/surge voltage suppressor (□Z)


(+) O (+) O (+) O (-) O (-

#### Non-polar type

With surge voltage suppressor (CR)




 Grommet or L/M-type plug connector With light/surge voltage suppressor (□U)



• DIN or Conduit terminal

With light/surge voltage suppressor (□U)




- Please connect correctly the lead wires to + (positive) and (negative) indications on the connector. (For non-polar type, the lead wires can be connected to either one.)
- When the valve with polarity protection diode is used, the voltage will drop by approx. 1 V. Therefore, pay attention to the allowable voltage fluctuation (For details, refer to the solenoid specifications of each type of valve).
- Solenoids, whose lead wires have been pre-wired: + (positive) side red and (negative) side black.


#### With power saving circuit

Power consumption is decreased by approx. 1/3 by reducing the wattage required to hold the valve in an energized state. (Effective energizing time is over 40 ms at 24 VDC.) Refer to the electrical power waveform as shown below.

#### <Electrical power waveform of energy saving type>




 Since the voltage will drop by approx. 0.5 V due to the transistor, pay attention to the allowable voltage fluctuation. (For details, refer to the solenoid specifications of each type of valve.)



#### <AC>

S type is not available, since a rectifier prevents surge voltage generation.



#### Residual voltage of the surge voltage suppressor

Note) If a varistor or diode surge voltage suppressor is used, there is some residual voltage to the protection element and rated voltage. Therefore, refer to the table below and pay attention to the surge voltage protection on the controller side. Also, since the response time does change, refer to the specifications on pages 809 and 823.

#### **Residual Voltage**

	D	AC	
Surge voltage suppressor	24 V	12 V	AC
S, Z	Appro	Approx. 1 V	
R, U	Approx. 47 V	Approx. 32 V	_

#### **Continuous Duty**

For applications such as mounting a valve on a control panel, incorporate measure to limit the heat radiation so that it is within the operating temperature range. Furthermore, do not touch it while it is being energized or right after it is energized.

© SMC



Be sure to read before handling. Refer to front matter 53 for Safety Instructions, pages 3 to 8 for 3/4/5 Port Solenoid Valves Precautions.

#### **One-touch Fittings Precautions**

# **▲**Caution

When fittings are used, they may interfere with one another depending on their types and sizes. Therefore, the dimensions of the fittings to be used should first be confirmed in their respective catalogs.

Fittings whose compliance with the VF series is already confirmed are stated below. If the fitting within the applicable range is selected, there will not be any interference.

#### Applicable Fittings: Series KQ2H, KQ2S

Series	Model	Piping port	Port size					0.D.			SYJ
				ø3.2	ø4	ø6	ø8	ø10	ø12	ø16	
VET	⊇20-□□1-M5	4(A), 2(B)	M5	$\frown$							SZ
VFIL		5(EA), 3(EB)	M5	$\square$							
VEI		4(A), 2(B)	1/8	$\frown$							VF
VEIL	VF1□20-□□1-01	5(EA), 3(EB)	M5	$\square$							VDA
VF1000 VF1	_3□-□□1-M5	4(A), 2(B)	M5	$\frown$							VP4
VF1	□3□-□□1-01	4(A), 2(B)	1/8	$\frown$							S0700
Type 3	30 manifold base	1(P), 5/3(R)	1/8	$\square$							00700
Turne 2	Type 31 manifold base	1(P)	1/8	$\square$							VQ
Type 3		5(EA), 3(EB)	M5	$\square$							

Series	Model	Piping port	Piping port Port size			Appli	cable tubing	J O.D.		
Series	Model	Piping port	Port size	ø3.2	ø4	ø6	ø8	ø10	ø12	ø16
	VF3□3□-□□1-01	4(A), 2(B)	1/8	$\frown$	1					
	VF3_31-01	1(P), 5(EA), 3(EB)	1/8	$\square$	1					
VF3_31-02 VF3_41-02	4(A), 2(B)	1/4	$\square$	1						
	1(P), 5(EA), 3(EB)	P: 1/4, EA, EB: 1/8	$\square$							
	4(A), 2(B)	1/4	$\square$							
	1(P), 5(EA), 3(EB)	1/4	$\square$							
	VF3□4□-□□1-03	4(A), 2(B)	3/8							
	VF3L4L-LL1-03	1(P), 5(EA), 3(EB)	3/8							
	Type 30 manifold base	1(P), 5(R), 3(R)	1/4			1				
	Type 40 manifold base	4(A), 2(B)	1/4		1	1	1			
		1(P), 5(R), 3(R)	1/4	$\frown$	1	1	1			

Oction	ries Model Piping port Ports		Dent size			Appli	cable tubing	0.D.		
Series Model	Piping port Port size	Port size	ø3.2	ø4	ø6	ø8	ø10	ø12	ø16	
	VF5□2□-□□1-02	4(A), 2(B)	1/4	$\square$	1	1				
		1(P), 5(EA), 3(EB)	1/4	$\square$	1	1		1		
	VF5□2□-□□1-03	4(A), 2(B)	3/8			$\square$				
		1(P), 5(EA), 3(EB)	3/8							
		4(A), 2(B)	1/4	$\square$	1	1				
	VF5044-001-02	1(P), 5(EA), 3(EB)	1/4	$\square$	1	1				
VF5000	VF5044-001-03	4(A), 2(B)	3/8							
VF5000	VF5L44-LL I-03	1(P), 5(EA), 3(EB)	3/8							
	VF5□44-□□1-04	4(A), 2(B)	1/2					$\square$		
	VF5U44-UU1-04	1(P), 5(EA), 3(EB)	1/2					$\square$		
	Type 20 manifold base	1(P), 5(R), 3(R)	3/8							
	Type 21 manifold base	1(P), 5(R), 3(R)	1/2							
	Type 40 manifold base	4(A), 2(B)	1/4		1	1				
		1(P), 5(R), 3(R)	3/8							

SJ



# Low Wattage Specification (VF1000/3000) Specific Product Precautions 6


Be sure to read before handling.

Refer to front matter 53 for Safety Instructions, pages 3 to 8 for 3/4/5 Port Solenoid Valves Precautions.

Manual Override

## **A Warning**

1. Non-locking push type [Standard]



#### 2. Push-turn locking slotted type [D type]

After pushing down, turn in the direction of the arrow. If it is not turned, it can be operated the same way as the non-locking push type.





### **∆**Caution

When operating the D type, use a watchmakers' screwdriver and turn lightly.

[Torque: Less than 0.1 N·m]

#### 3. Push-turn locking lever type [E type]

After pushing down, turn in the direction of the arrow. If it is not turned, it can be operated the same way as the non-locking push type.





#### ▲Caution

When locking the manual override with the push-turn locking type (D or E type), be sure to push it down before turning. Turning without first pushing it down can cause damage to the manual override and other trouble such as air leakage, etc.

#### Solenoid Valve for 200/220 VAC Specification

## **M**Warning


AC specification solenoid valves with grommet or L/M-type plug connector have a built-in rectifier circuit in the pilot section to operate the DC coil. With 200/220VAC specification pilot valves, this built-in rectifier generates heat when energized. The surface may become hot depending on the energized condition; therefore, do not touch the solenoid valves.

#### How to Use L/M-Type Plug Connector

## ▲ Caution

#### 1. Connector attachment/detachment


- To attach a connector, hold the lever and connector unit between your fingers and insert straight onto the pins of the solenoid valve so that the lever's pawl is pushed into the groove and locks.
- To detach a connector, remove the pawl from the groove by pushing the lever downward with your thumb, and pull the connector straight out.



#### 2. Crimping lead wire and socket connection

Strip 3.2 to 3.7 mm at the end of the lead wires, insert the ends of the core wires evenly into the sockets, and then crimp with a crimping tool. When this is done, take care that the coverings of the lead wires do not enter the core wire crimping area.

(Please contact SMC for the dedicated crimping tools.)




#### 3. Socket with lead wire attachment/detachment

#### Attachment

Insert the sockets into the square holes of the connector (with +, – indication), and continue to push the sockets all the way in until they lock by hooking into the seats in the connector. (When they are pushed in, their hooks open and they are locked automatically.) Then, confirm that they are locked by pulling lightly on the lead wires.

#### Detachment

To detach a socket from a connector, pull out the lead wire while pressing the socket's hook with a stick having a thin tip (approx. 1 mm). If the socket will be used again, first spread the hook outward.







# Low Wattage Specification (VF1000/3000) Specific Product Precautions 6-1

Be sure to read before handling.


Refer to front matter 53 for Safety Instructions, pages 3 to 8 for 3/4/5 Port Solenoid Valves Precautions.

Plug Connector Lead Wire Length

## 🗥 Caution

Plug connector lead wires have a standard length of 300 mm, however, the following lengths are also available.

## How to Order Connector Assembly



DC	AC
VF3130Y-5LO1-02	VF3130Y-1LO1-02
SY100-30-4A-20	SY100-30-1A-20

SJ
SY
SY
SV
SYJ
SZ
VF
VP4
S0700
VQ
VQ4
VQ5
VQC
VQC4
VQZ
SQ
VFS
VFR
VQ7

**⊘**SMC



# Low Wattage Specification (VF1000/3000) **Specific Product Precautions 7**

Be sure to read before handling.

Refer to front matter 53 for Safety Instructions, pages 3 to 8 for 3/4/5 Port Solenoid Valves Precautions.


#### Light/Surge Voltage Suppressor

## **∧** Caution

1. L/M-type plug connector


#### <DC>





<AC>

-AC>



#### 2. DIN terminal


<DC> With surge voltage suppressor (DS, DOS, YS, YOS)



With light/surge voltage suppressor (DZ, YZ)



With indicator light (DZ, YZ)



Note) If a varistor surge voltage suppressor is used, there is some residual voltage to the protection element and rated voltage. Therefore, pay attention to the surge voltage protection on the controller side.

#### How to Use DIN Terminal

1. ISO#: Conforming to EN-175301-803C (former DIN 43650C) (Distance between pins: 8 mm)

The DIN terminal type with an IP65 (enclosure) is protected against dust and water, however, it must not be used in water.


#### 2. Connection

- 1) Loosen the set screw and pull the connector out of the solenoid valve terminal block.
- 2) After removing the set screw, insert a flat head screwdriver, etc. into the notch on the bottom of the terminal block and pry it open, separating the terminal block and the housing.
- 3) Loosen the terminal screws (slotted head screw) on the terminal block, insert the core of the lead wire into the terminal according to wiring connection, and attach securely with the terminal screws. 4) Tighten the ground nut to secure the wire.

#### 3. Changing the entry direction

After separating the terminal block and housing, the cord entry direction can be changed by attaching the housing in a different direction (four directions at 90° intervals).

\* Make sure not to damage a light, etc., with the lead wires of the cord



How to Use DIN Terminal

## **DIN Connector Part No.**

## \land Caution

#### DIN terminal (D)

• • • • • • • • • • • • • • • • • • • •					
Without indicator light	SY100-61-1				
With indicator light					
Rated voltage	Voltage symbol	Part no.			
24 VDC	24 V	SY100-61-3-05			
12 VDC	12 V	SY100-61-3-06			
100 VAC	100 V	SY100-61-2-01			
200 VAC	200 V	SY100-61-2-02			
110 VAC	110 V	SY100-61-2-03			
220 VAC	220 V	SY100-61-2-04			


#### DIN terminal (Y)

Without indicator light							
Rated voltage	Voltage symbol	Part no.					
Common to all voltages	None	SY100-82-1					

#### . . . . . . . .

with indicator light	t	
Rated voltage	Voltage symbol	Part no.
24 VDC	24 V	SY100-82-3-05
12 VDC	12 V	SY100-82-3-06
100 VAC	100 V	SY100-82-2-01
200 VAC	200 V	SY100-82-2-02
110 VAC (115VAC)	110 V	SY100-82-2-03
220 VAC (230 VAC)	220 V	SY100-82-2-04

#### Circuit diagram with light



SJ