# Flow Sensor




# For suction verification of very small workpieces

The flow sensor enables more reliable suction verification than a pressure sensor.


New A measuring flow rate range of 0.0 New 3-Screen Display to 0.1 L/min (-x502) has been added.


**Flow Sensor** PFMV5 Series p. 6



- Voltage display/flow rate display Sensor voltage display/flow rate display can be selected in the
- Settable switch output It is possible to change the settings while checking the measured value.
- Dedicated monitor for the PFMV5







(Comparison with a nozzle diameter of Ø0.3 at a vacuum pressure of -60 kPa)

■ Repeatability: ±2% F.S.

■ Response speed: 5 ms or less

■ Withstand pressure: 500 kPa

Grease-free


Model		Dongo	Rated flow range [L/min]							
		Range	-3.0	-1.0	-0.5	0	0.1	0.5	1.0	3.0
(1	lew 505-X502	0.1 L/min								
PFMV	505	0.5 L/min								
	510	1.0 L/min								
	530	3.0 L/min								
	505F	±0.5 L/min								
	510F	±1.0 L/min					-			
	530F	±3.0 L/min								





### **Compact and Lightweight**

The taper-shaped flow passage in front of the sensor chip enables stable sensing.





### **Space-saving piping**


The product is mountable in locations with limited space as piping space is not required.




# With a bend-resistant cable

### **Mounting**


Direct mounting



Single-side bracket mounting




Manifold mounting




 Both-side bracket mounting

# **Applications**

- For suction verification of very small workpieces
- · Suction of small components can be verified.
- · Highly applicable to small nozzles.
- · Nozzle clogging and crushing can be detected.



- For leakage testing of 0.1 L/min or less
- · Pin holes in molded parts can be easily detected.








# 3-Screen Display Digital Flow Monitor PFGV301 Series 5.13


# Allows for the monitoring of remote lines




### Visualization of settings










# Easy screen switching




The sub screen can be switched by pressing the up/down buttons.




\* Either "Input of line name" or "Display OFF" can be added via the function settings.

# Simple 3-step setting

When the S button is pressed and the set value  $(P_1)$  is being displayed, the set value (threshold value) can be set. When the S button is pressed and the hysteresis  $(H_1)$  is being displayed, the hysteresis value can be set.





### NPN/PNP switch function


The number of stock items can be reduced.







### Input range selection (for Pressure/Flow rate)



The displayed value to the sensor input can be set as required. (Voltage input: 1 to 5 V)

Pressure switch/Flow switch can be displayed.

A is displayed for 1 V.


B is displayed for 5 V. The range can be set as required.

### Analog output of 0 to 10 V is also available.

Valtage cutout	1 to 5 V	Switchable	
Voltage output	0 to 10 V	Switchable	
Current output	4 to 20 mA	Fixed	

### ■ Pressure Sensor for General Fluids/PSE570





	Α	В
<b>PSE570</b>	0	1000
<b>PSE573</b>	-100	100
PSE574	0	500

Set A and B to the values shown in the table above.

### **Convenient functions**

Copy function The set values of the monitor can be copied.



Security code

The key locking function keeps unauthorized persons from tampering with the settings.

### Power saving function

Power consumption is reduced by turning off the monitor.


Current consumption*1	Reduction rate*2
25 mA or less	Approx. 50% reduction
*1 During normal operation	*2 In power saving mode

### External input function

The accumulated value, peak value, and bottom value can be reset remotely.

### **Compact & Lightweight**

- Compact: Max. 6 mm shorter
- Lightweight: Max. 5 g lighter (30 g → 25 g)




Output operation

**Functions** 

- Simple setting mode
- Display color
- Delay time setting
- Digital filter setting
- Selectable analog output function
- External input function
- Auto-shift function
- Forced output function
- Peak/Bottom value display
- FUNC output switching function
   Setting of a security code
- Key-lock function
- Reset to the default settings
- Display with zero cut-off setting
- Auto-preset function
- Selection of the display on the sub screen
- Analog output free range function
- Error display function
- Copy function
- Selection of power saving mode

## Mounting

Bracket configuration allows for mounting in four orientations.





### Panel mounting

Mountable side by side without clearance

### One opening!

- · Reduced panel fitting labor
- · Space saving





# CONTENTS

# Flow Sensor *PFMV5 Series*3-Screen Display Digital Flow Monitor *PFGV301 Series*



Flow	Sensor	PFMV5	Series

How to Order	p. 6
Specifications	p. 7
Internal Circuits and Wiring Examples	p. 7
Recommended Pneumatic Circuits	p. 8
Recommended Fittings	p. 8
Wetted Parts Construction	p. 8
Detection Principle	p. 8
Analog Output (Non-linear output)	p. 9
Pressure Loss	p. 10
Dimensions	p. 11
Related Equipment Compact Suction Filter	p. 12

Model Selection -----p. 5



3-Screen Display	Digital	Flow	Monitor	PFGV301	Series
------------------	---------	------	---------	---------	--------

How to Order	·····p. 13
Specifications	p. 14
Display Accuracy and Repeatability when Combined	
with PFMV5. (Calculation Example)	p. 15
Settable Range and Voltage Input Range	p. 16
Internal Circuits and Wiring Examples	p. 17
Dimensions	p. 18
Made to Order	p. 21

Safety Instructions Back cover



# **PFMV** Series **Model Selection**


### Nozzle Diameter and Flow Rate Characteristics (Approximate values)


Use the following graphs as a reference to select sensor measuring range.


P2: Nozzle internal pressure



### Nozzle Diameter - Flow Rate Characteristics (Vacuum)







### **Example (Vacuum)**


Selecting conditions:

Nozzle diameter: Ø0.3 P1: 0 [kPa]

P2: -60 [kPa]

The flow rate will be 0.7 to 0.8 [L/min] based on the graph.

 $\rightarrow$  Select the PFMV510-1.



### **Example (Positive pressure)**


Selecting conditions:

Nozzle diameter: ø0.3 P1: 0 [kPa]

P2: 20 [kPa]

The flow rate will be 0.7 to 0.8 [L/min] based on the graph.


 $\rightarrow$  Select the PFMV510-1.



\* Since the calculated value may not meet the approximate value due to leakage and pressure loss in the piping system, please check the result by using actual equipment.

# Flow Sensor PFNV5 Series






### Option/Part Nos.

If a single option or manifold mounting are required, order sensors with the part numbers below separately.

Part no.	Stations	Note
ZS-36-A1	For 1 station (for single unit)	2 L-type brackets, 2 mounting screws M3 x 15L
ZS-36-A2	For 2 stations	2 L-type brackets, 2 mounting screws M3 x 25L
ZS-36-A3	For 3 stations	2 L-type brackets, 2 mounting screws M3 x 35L
ZS-36-A4	For 4 stations	2 L-type brackets, 2 mounting screws M3 x 45L
ZS-36-A5	For 5 stations	2 L-type brackets, 2 mounting screws M3 x 55L



# **PFMV5** Series

### **Specifications**

For flow switch precautions and specific product precautions, refer to the "Operation Manual" on the SMC website.




Model		PFMV505-X502	PFMV505	PFMV510	PFMV530	PFMV505F	PFMV510F	PFMV530F		
Annlicable	Applicable fluid		Dry air, №							
Applicable fluid		(JIS B 8392-1 1.1.2 to 1.6.2: 2003, ISO 8573-1 1.1.2 to 1.6.2)								
*1 Rated flow range (Flow rate range)		0 to 0.1	0 to 0.5	0 to 1	0 to 3	-0.5 to 0.5	-1 to 1	-3 to 3		
		L/min	L/min	L/min	L/min	L/min*2	L/min*2	L/min*2		
Accuracy				=	±5% F.S.*3					
Repeatabi	<b>*</b>				±2 F.S.*3					
Pressure ( 0 kPa refe	characteristics erence*4)				F.S. (0 to 300 k F.S. (–70 to 0 k	,				
Temperati	ure characteristics				F.S. (15 to 35° F.S. (0 to 50° C	,				
•	ssure range*5				70 kPa to 300 k					
	pressure range*6			-10	00 kPa to 400 k	Pa				
Proof pres	•	500 kPa								
Analog output (Non-linear output)		Voltage output: 1 to 5 V, Output impedance: Approx. 1 kΩ								
Response	time	5 ms or less (90% response)								
Power sup	pply voltage	12 to 24 VDC ± 10% (With polarity protection)								
Current co	onsumption	16 mA or less								
	Enclosure	IP40								
	Fluid temperature	0 to 50°C (No freezing and condensation)								
	Operating temperature range	0 to 50°C (No freezing and condensation)								
	Stored temperature range	-10 to 60°C (No freezing and condensation)								
Environ-	Operating humidity range	35 to 85% R.H. (No condensation)								
ment	Stored humidity range	35 to 85% R.H. (No condensation)								
	Withstand voltage		1000 VAC for 1 minute between terminals and housing							
	Insulation resistance	50 ${ m M}\Omega$ or more (500 VDC measured via megohmmeter) between terminals and housing								
	Port size		M5	x 0.8 (Tightening	ng torque: Appr	ox. 0.5 to 1.0 N	l·m)			
	Wetted parts material		PPS, Si, A	u, Stainless ste	el 316, C3604	(Electroless nic	kel plating)			
Standards		CE/UKCA marking, UL (CSA)								
Lead wire			\	/inyl cabtire cor	d, 3 cores ø2.6	5, 0.15 mm <sup>2</sup> , 2 n	n			
Weight				10 g (	Excluding lead	wire)				

- \*1 The flow rate given in the specifications is the value under standard conditions.
  \*2 Analog output indicates 3 V when the flow rate is 0. When the flow direction is from IN to OUT, the output is changed to 5 V, and when it's from OUT to IN, the output is \*2 Analog output indicates 5 v when the new rate is 0. When the inchanged to 1 V.
  \*3 The unit % F.S. is based on the full scale of analog 4 V (1-5 V).
  \*4 0 kPa indicates the atmospheric release.
  \*5 Pressure range that satisfies the product specifications

- Applicable pressure range
   Every product of the "Operation Manual" on the SMC website, https://www.smcworld.com
   Products with tiny scratches, marks, or display color or brightness variations which do not affect the performance of the product are verified as conforming products.

### **Internal Circuits and Wiring Examples**

### -1 Analog voltage output



### **Lead Wire Specifications**

Conductor	Nominal cross section area	AWG26
Conductor	External diameter	0.58 mm
Insulator	External diameter	0.88 mm
insulator	Colors	Brown, Blue, Black
Sheath Material		Oil-resistant/Heat-resistant PVC
Finished ex	ternal diameter	2.6



### **Recommended Pneumatic Circuits**

# Compressed air line



IDF AF AR AFM AFD PFMV IDU IR AM AMD

### Recommended Fittings

### One-touch Fitting/KQ2 Series

Туре	Tubing O.D. [mm]	Port size	Model
Male connector	4	M5 x 0.8	KQ2H04-M5A
Male elbow	4	O.U X CIVI	KQ2L04-M5A

### Miniature Fitting/M Series

Туре	Tubing O.D. [mm]	Port size	Model
Borb fitting for pulon tube	4	M5 x 0.8	M-5AN-4
Barb fitting for nylon tube	6	1VIS X U.8	M-5AN-6


### Compact Suction Filter p. 12

Part no.	Connection type	
ZFC050-M5X68	IN/OUT: M5	
ZFC050-AU6X68	IN: ø6 barb fitting OUT: M5	
ZFC-EL013-A	Element (10 pcs.)	





**Wetted Parts Construction** 



### **Component Parts**

No.	Description	Material	
1	Fitting for piping	C2604 (Floatrologo pickol plating)	
2	Mesh holding screw	C3604 (Electroless nickel plating)	
3	Mesh	Stainless steel 316	
4	Body	PPS	
5	Print circuit board	GE4F	
6	Sensor chip	Si, Au	


### **Detection Principle**

This MEMS sensor chip consists of upstream temperature measuring sensor (Ru) and down-stream temperature measuring sensor (Rd), which are placed symmetrically from the center of a platinum thin film coated heater (Rh) mounted on a membrane, and an ambient temperature sensor (Ra) for measuring gas temperature.

The principle is shown as the diagram on the right. (a) When the gas is static, the temperature distribution of heated gas centered around Rh is uniform, and Ru and Rd have the same resistance. (b) When the gas flows from the left side, it upsets the balance of the temperature distribution of heated gas, and the resistance of Rd becomes greater than that of Ru.

The difference in resistance between Ru and Rd is proportional to the flow velocity, so measurement and analysis of the resistance can show the flow direction and velocity of the gas.

Ra is used to compensate the gas and/or ambient temperature.




(b) The gas flows from the left side.




# **PFMV5** Series

### **Analog Output (Non-linear output)**


### PFMV505-1-X502




### PFMV505-1




### PFMV510-1




### PFMV530-1




### PFMV505F-1



### PFMV510F-1




### PFMV530F-1




- \* Use these graphs as a reference for calculating the flow rate value.
- Due to slight differences between individual products, the values may not match the values shown in the graphs. Confirm with the actual product before use.

### **Pressure Loss (Reference Data)**


### PFMV505(F)-1(-X502)



### PFMV510(F)-1




### PFMV530(F)-1





# **PFMV5** Series


### **Dimensions**

















### One-side bracket

### **Both-side bracket**









10 x n pcs. + 24 (n = 1 to 5)


10 x n pcs. + 14 (n = 1 to 5)

FLOW SENSO


10

# **ZFC050**

# **Related Equipment**



### Example of mounting to the flow sensor PFMV series (For suction verification)



### **Specifications**

Filtration degree	3 μm (Nominal)
Fluid	Air
Operating pressure range	-100 to 600 kPa
Ambient temperature	0 to 60°C (No freezing)
Applicable tubing material	Soft nylon, Polyurethane
Applicable tubing O.D./I.D.	ø6/ø4

### Replacement element part no....ZFC-EL013-A

### **⚠** Caution

- 1. To screw in OUT side port (M5 male thread), tighten by hand before giving it an additional 1/4 turn with a tightening tool.
- 2. When replacing the element, remove the IN side body using the hexagon surface on the IN side, then replace the element. After replacing the element, tighten the IN side body with the tightening torque 0.5 to 0.7 N·m.
- 3. As a rule, replace the element when the pressure drops by 20 kPa.
- 4. The response time of the single flow sensor is 5 msec. However, take great care since the response may be delayed depending on the element clogged conditions.



# 3-Screen Display

# Digital Flow Monitor ( E CA CA LA US PFGV301 Series







# PFGV 3 0 1 - RT - M - I

Innut appoification

		iliput specification
Symbol	Description	Applicable flow switch model
0	Voltage input	PFMV5 series

3 Remote type monitor unit

### Output specification •

RT	2 outputs (NPN/PNP switching type) + Analog voltage output*1, 2	
sv	2 outputs (NPN/PNP switching type) + Analog current output*2	
ΧY	2 outputs (NPN/PNP switching type) + Copy function	

- \*1 Can switch between 1 to 5 V and 0 to 10 V
- \*2 Can be switched to external input or copy function

### Unit specification •

Nil	Unit selection function*3
M	SI unit only*4

- \*3 This product is for overseas use only. (The SI unit type is provided for use in Japan in accordance with the New Measurement Act.)
- \*4 Fixed units: Instantaneous flow: L/min Accumulated flow: L

### Option 4

	Operation manual	Calibration certificate
Nil	0	_
Υ	_	_
K	0	0
Т	_	0

### Option 3

• Option 3		
Nil	None	
	ZS-28-C	
С	Sensor connector	

### Option 1


		Option 1 *	
Symbol	Description		
Nil	Without lead wire	Without lead wire	
L	Power supply/output connection lead wire (Lead wire length: 2 m)	Power supply/output connection lead wire	

### Options/Part Nos.

When only optional parts are required, order with the part numbers listed below.

Part no.	Option	Note
ZS-28-C	Sensor connector	For PFMV5□
ZS-46-A1	Bracket A	Tapping screw: Nominal size 3 x 8 L (2 pcs.)
ZS-46-A2	Bracket B	Tapping screw: Nominal size 3 x 8 L (2 pcs.)
ZS-46-B	Panel mount adapter	
ZS-46-D	Panel mount adapter + Front protection cover	
ZS-46-5L	Power supply/output connection lead wire	5-core, 2 m
ZS-27-01	Front protection cover	
ZS-28-A-X538	PFMV30□ → PFGV301 conversion cable	Made to Order (Refer to page 21.)

### **Connection Example**



♦ Option 2		
Symbol	[	Description
Nil	None	
<b>A</b> 1	Bracket A (Vertical mounting)	ZS-46-A1
<b>A</b> 2	Bracket B (Horizontal mounting)	ZS-46-A2
В	Panel mount adapter	ZS-46-B
D	Panel mount adapter + Front protection cover	ZS-46-D



# 3-Screen Display Digital Flow Monitor **PFGV301** Series

For flow switch precautions and specific product precautions, refer to the "Operation Manual" on the SMC website.



### **Specifications**

	Model				F	PFGV301 serie			
Applicable flow			PFMV505-X502	PFMV505	PFMV510	PFMV530	PFMV505F	PFMV510F	PFMV530F
Rated voltage range		1.00 to 5.00 V							
Voltage	Set voltage range					0.80 to 5.20 V			
	Smallest settable increment								
			0 to 0.1	0 to 0.5	0 to 1	0 to 3	-0.5 to 0.5	-1 to 1	-3 to 3
Flow	Rated flow range*1		L/min	L/min	L/min	L/min	L/min	L/min	L/min
	Set point range		-0.005 to 0.105 L/min	-0.025 to 0.525 L/min	-0.05 to 1.05 L/min	-0.15 to 3.15 L/min	-0.525 to 0.525 L/min	-1.05 to 1.05 L/min	-3.15 to 3.15 L/min
	Smallest settable increment		0.001	L/min	0.01	L/min	0.001 L/min	0.01	L/min
	Power supply voltage		12 to 24 VDC ±10% or less						
Electrical	Current consumption		25 mA or less						
	Protection		Polarity protection						
	Display accuracy		±0.5% F.S. ± Min. display unit (Ambient temperature at 25°C)						
A · · * ?	Analog output accuracy		±0.5% F.S. (Ambient temperature at 25°C)						
Accuracy*2	Repeatability		±0.1% F.S. ± Min. display unit, Analog output: 0.3% F.S. or less						
	Temperature characteristics		±0.5% F.S. (Ambient temperature: 0 to 50°C, 25°C standard)						
	Output type						collector output		
	Output mode		Select				output, or Switc		nodes.
	Switch operation			,		Normal or Reve			
	Max. load current					80 mA			
	Max. applied vo				3	0 V (NPN outpu	ıt)		
Switch output	Internal voltage drop		NPN output: 1 V or less (at load current of 80 mA), PNP output: 1.5 V or less (at load current of 80 mA)						
отположерат	Response time		r. output		<u> </u>	3 ms or less		, oo (at 10aa 0a.1	<u> </u>
	Delay time*3		Select from 0, 0.05 to 0.10 s (increments of 0.01 s), 0.1 to 1.0 s (increments of 0.1 s),						
	Hysteresis*4		1 to 10 s (increments of 1 s), 20 s, 30 s, 40 s, 50 s, or 60 s.  Variable from 0						
	Protection		Short circuit protection						
Analog output*5	Output type		Voltage output: 1 to 5 V (0 to 10 V can be selected only when the power supply voltage is 24 VDC)*6,  Current output: 4 to 20 mA						
	Impedance Voltage output		· · · · · · · · · · · · · · · · · · ·						
	Response time*2		50 ms or less						
	Peak/Bottom Input type		Input voltage: 0.4 V or less (Reed or Solid state) for 30 ms or longer						
	value reset Input mode		, , ,						
External input*7	Auto-shift	Input type	Input voltage: 0.4 V or less (Reed or Solid state) for 5 ms or longer						
	input	Input mode		input voita	<u> </u>			3 or longer	
	· · · · · · · · · · · · · · · · · · ·		Select from Auto-shift or Auto-shift zero.  Voltage input: 1 to 5 VDC (Input impedance: 1 $M\Omega$ )						
Sensor input	Input type		Connector (e-CON)						
Sensor input	Connection method		Over voltage protection (Up to 26.4 VDC)						
	Protection								
	Display mode Unit*8		Instantaneous flow display						
	Oille -	Voltage	L/min, cfm (ft³/h)  0.80 to 5.20 V						
	Display range	Flow	-0.005 to	-0.025 to	-0.05 to	-0.15 to	-0.525 to	-1.05 to	-3.15 to
	Min. display	Voltage	0.105 L/min	0.525 L/min	1.05 L/min	3.15 L/min 0.01 V	0.525 L/min	1.05 L/min	3.15 L/min
Display	unit		0.001	I /min	0.01		0.001 L/min	0.01	l /min
	1		0.001 L/min						
	Display type		3-screen display (Main screen, Sub screen)						
	Number of displays								
	Display color		1) Main screen: Red/Green, 2) Sub screen: Orange 1) Main screen: 5 digits (7 segments), 2) Sub screen: 9 digits (7 segments)						
	Number of display digits		LED ON when switch output is ON. OUT1/2: Orange						
	Indicator LED								
Digital filter*9			Select from 0, 0.05 to 0.10 s (increments of 0.01 s), 0.1 to 1.0 s (increments of 0.1 s), 1 to 10 s (increments of 1 s), 20 s, or 30 s.						
	Enclosure		IP40						
Environmental resistance	Withstand voltage		1000 VAC for 1 min between terminals and housing						
	Insulation resistance		$50~\text{M}\Omega$ or more (500 VDC measured via megohmmeter) between terminals and housing						
i coiotaiile	Operating temperature range		Operating: 0 to 50°C, Stored: –10 to 60°C (No condensation or freezing)						
	Operating humidity range		Operating/Stored: 35 to 85% RH (No condensation or freezing)						
Standards	, <u>,                                    </u>	, ,	CE/UKCA marking, UL (CSA)						
	Body		25 g (Excluding the power supply/output connection lead wire)						
Weight	Lead wire with connector		+39 g						
	, ,		l						


- \*1 Rated flow range of the applicable flow sensor. The flow rate stated in the specifications is for under normal conditions (20°C, 101.3 kPa (absolute
- \*2 The accuracy is with respect to the voltage display. When the flow rate display function is selected, the display accuracy and repeatability should be exactly like the graph on page 15.
- \*3 Value without digital filter (at 0 ms)
- \*4 If the flow fluctuates around the set value, be sure to keep a sufficient margin. Otherwise, chattering will occur.
- \*5 Setting is only possible for models with analog output.
  \*6 When selecting 0 to 10 V, refer to the analog output graph for the allowable load current.
- Setting is only possible for models with external input.
- \*8 Setting is only possible for models with the unit selection function.
- \*9 The response time indicates when the set value is 90% in relation to the
- \* Products with tiny scratches, marks, or display color or brightness variations which do not affect the performance of the product are verified as conforming products.



# PFGV301 Series

### Display Accuracy and Repeatability when Combined with PFMV5. (Calculation Example)

### PFMV530-1



When the flow rate display function for the PFGV301 series is selected, calculate the repeatability from the analog output characteristics graph (page 9).

### Example) For PFMV530-1 (0 to 0.3 L/min)

- ① When the actual flow rate is 0.3 L/min, the PFMV530-1 outputs approximately 2.5 V of analog voltage (Arrow ① in the graph on the left).
- ② The PFMV5 series has a repeatability of ±2% F.S. (±80 mV) (Arrow ② in the graph on the left).
- ③ When this accuracy is converted to a flow rate, it becomes approximately  $\pm 3\%$  F.S. ( $\pm 0.09$  L/min), and this width becomes the repeatability when the flow rate is displayed (arrow ③, and the width of  $\triangle$  Q, in the graph on the left).

The flow rate display accuracy can be also calculated from the PFMV5 series accuracy (±5% F.S.).




# 3-Screen Display Digital Flow Monitor **PFGV301** Series

### Settable Range and Voltage Input Range

The settable rate range is the range that can be set in the switch.

The inputtable range is the range that satisfies the switch specifications (accuracy, linearity, etc.).


It is possible to set a value outside of the inputtable range if it is within the settable range, however, the specification is not guaranteed.



The settable rate range is the flow range that can be set in the switch.

The rated flow range is the flow rate range that satisfies the switch specifications (accuracy, linearity, etc.).

It is possible to set a value outside of the rated flow range if it is within the settable range, however, the specification is not guaranteed.



The values shown on the graph are the displayed flow rate range and set flow rate range when PFMV5 series and PFGV301 series are connected.

Rated flow range Displayable flow range Settable range




## PFGV301 Series

### **Internal Circuits and Wiring Examples**


-XY

-RT -SV


### NPN (2 outputs) + Copy function



### -RT: NPN (2 outputs) + Analog voltage output -SV: NPN (2 outputs) + Analog current output




### -RT: NPN (2 outputs) + External input -SV: NPN (2 outputs) + External input




-XY

-RT


### PNP (2 outputs) + Copy function




### -RT: PNP (2 outputs) + Analog voltage output -SV: PNP (2 outputs) + Analog current output





### -RT: PNP (2 outputs) + External input -SV: PNP (2 outputs) + External input




### **Dimensions**









Bracket A (Part no.: ZS-46-A1)







25




Bracket configuration allows for mounting in four orientations.


Bracket B (Part no.: ZS-46-A2)







\* Bracket configuration allows for mounting in four orientations.







# **PFGV301** Series


### **Dimensions**


# Panel mount adapter (Part no.: ZS-46-B)






# Panel mount adapter + Front protection cover (Part no.: ZS-46-D)






# Power supply/output connection lead wire (Part no.: ZS-46-5L)



# Sensor connector (Part no.: ZS-28-CA)

Pin no.	Terminal			
1	DC (+)			
2	N.C.			
3	DC (-)			
4	IN*1			
*1 1 to 5 V				




### **Cable Specifications**


Cable 3	pecifications			
Conductor cross section		0.15 mm <sup>2</sup> (AWG26)		
Insulator	Outside diameter	1.0 mm		
	Color	Brown, Blue, Black, White, Gray (5-core)		
Sheath	Finished outside diameter	ø3.5		

### **Dimensions**


### Panel fitting dimensions




Multiple (2 pcs. or more) secure mounting <Horizontal>




Panel mount example <Horizontal>



<Vertical>



Panel mount example <Vertical>





# **PFGV301** Series **Made to Order**



Please contact SMC for detailed dimensions, specifications, and delivery times.


# 1 Conversion Cable for the PFMV30□ Lead Wire with Connector

The conversion cable allows for connection between the existing PFMV30□ lead wire with connector and the PFGV301.

### PFMV30□ → PFGV301 + Conversion Cable Correspondence Table

Existing flow monitor model	Output specification	① Flow monitor part no.	② Conversion cable part no.
PFMV300-□□□□-□□	NPN 2 outputs + 1–5 V outputs	PFGV301-RT-□-□□□□	
PFMV301-□□□□-□□	NPN 2 outputs + 4–20 mA output	PFGV301-SV-□-□□□□	
PFMV302-□□□□-□□	NPN 2 outputs + auto-shift input	PFGV301-XY-□-□□□□	ZS-28-A-X538
PFMV303-□□□□-□□	PNP 2 outputs + 1–5 V outputs	PFGV301-RT-□-□□□□	23-20-A-A330
PFMV304-□□□□-□□	PNP 2 outputs + 4-20 mA output	PFGV301-SV-□-□□□□	
PFMV305-□□□□-□□	PNP 2 outputs + auto-shift input	PFGV301-XY-□-□□□□	

### ZS-28-A-X538



# **⚠** Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "Caution," "Warning" or "Danger." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)\*1), and other safety regulations.

⚠ Danger: Danger indicates a hazard with a high level of risk which, If not avoided, will result in death or serious injury.

Warning: Warning indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.

⚠ Caution: Caution indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.

\*1) ISO 4414: Pneumatic fluid power - General rules and safety requirements for systems and their components ISO 4413: Hydraulic fluid power - General rules and safety requirements for systems and their components IEC 60204-1: Safety of machinery - Electrical equipment of machines - Part 1: General requirements ISO 10218-1: Robots and robotic devices - Safety requirements for industrial robots - Part 1:Robots

### **⚠Warning**

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalog information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

- 3. Do not service or attempt to remove product and machinery/ equipment until safety is confirmed.
  - 1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
  - 2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
  - 3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.
- 4. Our products cannot be used beyond their specifications. Our products are not developed, designed, and manufactured to be used under the following conditions or environments. Use under such conditions or environments is not covered.
  - 1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
  - 2. Use for nuclear power, railways, aviation, space equipment, ships, vehicles, military application, equipment affecting human life, body, and property, fuel equipment, entertainment equipment, emergency shut-off circuits, press clutches, brake circuits, safety equipment, etc., and use for applications that do not conform to standard specifications such as catalogs and operation manuals.
  - 3. Use for interlock circuits, except for use with double interlock such as installing a mechanical protection function in case of failure. Please periodically inspect the product to confirm that the product is operating properly.

### **⚠** Caution

We develop, design, and manufacture our products to be used for automatic control equipment, and provide them for peaceful use in manufacturing industries.

Use in non-manufacturing industries is not covered.

Products we manufacture and sell cannot be used for the purpose of transactions or certification specified in the Measurement Act.

The new Measurement Act prohibits use of any unit other than SI units in

### Limited warranty and Disclaimer/ Compliance Requirements

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".

Read and accept them before using the product.

### **Limited warranty and Disclaimer**

- 1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, whichever is first.\*2) Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
- 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- 3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalog for the particular products.
  - \*2) Vacuum pads are excluded from this 1 year warranty. A vacuum pad is a consumable part, so it is warranted for a year after it is delivered. Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

### **Compliance Requirements**

- 1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
- 2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

### **Revision History**

Edition B \* A flow rate display function has been added to the voltage monitor for the PFMV3. NS

Edition C \* Not available

Edition D \* The PFMV3 has been changed to the PFGV3.

The PFMV505-X502 has been added.

↑ Safety Instructions Be sure to read the "Handling Precautions for SMC Products" (M-E03-3) and "Operation Manual" before use.

## **SMC** Corporation

Akihabara UDX 15F.

4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101-0021, JAPAN Phone: 03-5207-8249 Fax: 03-5298-5362

https://www.smcworld.com

© 2024 SMC Corporation All Rights Reserved