Pilot Operated 2 Port Solenoid Valve for Dry Air VQ20/30 Series

		oot on	d liabtwaiak	N CA ^[Option]	1
	Jub	Weight (g)	C [dm ³ /(s·bar)]	it with large flow capacity	
V	/Q20	46	1.5 (C8)		
	/Q30	80	3.0 (C12)		
6				VQ30 Series	
			6666	C LO N	VCHD VDW
e e	0		610		SX10
	C		VQ20	Series	VQ LVM
Hid	ah fr	equen	cy operation	n nossihle	
	-	-), 20 ms or less (VQ30)	
_	-	-		oltage suppressor at the supply pressure of 0.5 MPa)	

Long operating life

Easy piping with One-touch Fittings

Dusttight low jetproof enclosure (IP65) compliant in DIN terminal type.

Application: Air-blow, Blow-off of workpiece, etc.

Pilot Operated For Dry Air

2 Port Solenoid Valve **VQ20/30 Series** Single Unit

How to Order Valves VQ 2 1 A :6 Series/ CE/UKCA-compliant Orifice diameter Nil Symbol Series 0 CE/UKCA-compliant 2 VQ20 Made to Order 3 VQ30 specifications (Refer to the table below) Valve type Option N.C. 2 (OUT) Nil: None 1 $|7 \triangleright$ W F: With bracket 1 (IN) When the valve is closed, flow is blocked from port 1 to port 2. However, if the pressure in port 2 Manual override is higher than port 1, the valve will not be able to block the fluid and it will flow from port 2 to port 1. Nil None L: Type L BNot Slotted locking type (VQ20 only) Body type (tool required) Note) Only normally closed DIN ter-Note 1) If ordering both options, indicate "LF" minal in-line type is applicable. Note 2) "M: For manifold" cannot be selected for A: Single unit the type with a bracket or Type L. Port size Port size VQ20 VQ30 Symbol C6 One-touch fitting for ø6 C8 One-touch fitting for ø8 M: For manifold C10 One-touch fitting for ø10 C12 One-touch fitting for ø12 Electricity circuit AC voltage Symbol DC voltage Coil voltage With power-saving circuit (With surge voltage suppressor protection circuit) With full wave rectifier circuit Nil (With surge voltage suppressor protection circuit) 100 VAC (50/60 Hz) 1 With full wave rectifier circuit (With light/surge voltage suppressor protection circuit) With power-saving circuit 200 VAC (50/60 Hz) 7 2 (With light/surge voltage supp ssor protection circuit) 3 110 VAC (50/60 Hz) H Note) High speed response type (Without energy-saving, light/surge voltage suppressor circuit) 4 220 VAC (50/60 Hz) Note) H is available only for DC voltage and cannot be energized continuously. 5 24 VDC 6 12 VDC 9 Other special voltage Made to Order Specifications For detailed specifications, contact SMC. Note 1) There is polarity for DC voltage (with power-saving circuit type). **Oil-free specifications** ·X2(-Q) Electrical entry Note) Please consult with SMC when using. Not available for manual operation. G: Grommet Seal material fluororubber specifications VQ31A1 -X5(-Q) Y: DIN terminal Seal material fluororubber/oil-free specifications $VQ_3^21_M^A1$ -X23(-Q) YO: DIN terminal Note) Not available for manual operation. without connector

@SMC

Pilot Operated 2 Port Solenoid Valve for Dry Air VQ20/30 Series

Standard Specifications

Series

666666 CC VQ20



Valve construction 2 port poppet pilot operated Air Note 1) Fluid Ambient and fluid temperature -10 to 50°C Note 2) specifications Lubrication Not required Slotted locking type (tool required) Note 3) Manual override 150/30 m/s^{2 Note 4)} Impact resistance/Vibration resistance Dustproof Note 5) /alve Enclosure Internal leakage cm3/min 15 or less Exterior leakage cm³/min 15 or less Mounting orientation Unrestricted 80 g Weight 46 g Coil rated voltage 12 VDC, 24 VDC, 100 VAC, 110 VAC, 200 VAC, 220 VAC specifications Allowable voltage fluctuation ±10% of rated voltage Coil insulation type Class B or equivalent DC voltage (with power-saving circuit) Inrush: 2.9 W, Holding: 0.6 W Power consumption DC voltage (without power-saving circuit) 2.9 W Electric (Current value) AC 2 V A Electrical entry Grommet, DIN terminal

VO20

VO30

Note 1) This product is for dry air. Use in clean air, and be sure that drain and oil content does not flow into the product. Note 2) Use dry air to prevent condensation when operating at low temperatures. Note 3) Manual override is available only for DIN terminal type.

Note 4) Vibration resistance: No malfunction occurred in a one-sweep test between 8.3 and 2000 Hz. Test was performed at both energized and de-energized states to the axis and right angle directions of the main valve and armature (value at the initial state).

Impact resistance: No malfunction resulted from the impact test using a drop impact tester. The test was performed on the axis and right angle directions of the main valve and armature for both energized and de-energized states (value at the initial state).

Note 5) DIN terminal type: Applicable to dusttight and low jetproof (IP65).

Characteristic Specifications

Se	ries	VQ	20	VQ30					
	Port size	ø6	ø8	ø10	ø12				
Flow rate		1.4	1.5	2.8	3.0				
characteristics	b	0.23	0.42	0.42	0.37				
	Cv	0.33	0.39	0.80	0.81				
Ain. operating pr	essure differential		0.01 MI	Pa Note 4)					
Max. operat	ing pressure	0.61	MPa	0.5	MPa				
Note 2)	Electricity circuit	With power-saving circuit	Note 3) High speed response type	With power-saving circuit	Note 3) High speed response type				
Response time	ON	10 ms or less	7 ms or less	25 ms or less	20 ms or less				
ume	OFF	15 ms or less	5 ms or less	15 ms or less	5 ms or less				

Note 1) The flow rate characteristics of this product have variations.

Note 2) JIS B 8373-2015 (Value of high response time is subject to change upon pressure, quality of air.) Note 3) It cannot be used when energized continuously.

Note 4) If a restrictor (nozzle, etc.) is mounted on the outlet side piping, the pressure differential when ON is smaller. Be sure that the pressure differential does not drop below 0.01 MPa. Additionally, take great care when used for the ejector supply, etc.

Construction



Component Parts

No.	Description	Material
1	Solenoid coil	_
2	Body	Resin
3	Fixed armature	Stainless steel
4	Armature	Stainless steel
5	Return spring	Stainless steel
6	Poppet	NBR
7	Diaphragm assembly	H NBR, Resin

ΗΠ

@SMC

1(IN

Symbol

N.C

When the valve is closed, flow is blocked from port 1 to port 2. However, if the pressure in port 2 is higher than port 1, the valve will not be able to block the fluid and it will flow from port 2 to port 1.

2 (OUT)

Dimensions: VQ20 Series

In-line Type: Grommet (G) VQ21A1-□G□-□-□









* Dotted line: Bracket mounting type (-F)

Dimensions: VQ20 Series

Type L: Grommet (G) VQ21A1-□G□-□-L□

VQ21A1-UGU-U-LU











Dimensions: VQ20 Series

In-line Type: DIN terminal (Y)

VQ21A1-□Y□□-□-□









* Dotted line: Bracket mounting type (-F)

Dimensions: VQ30 Series

In-line Type: Grommet (G) VQ31A1-□G□-□-□







* Dotted line: Bracket mounting type (-F)

Dimensions: VQ30 Series

DIN terminal (Y)

VQ31A1-0Y00-0-0







C10: One-touch fitting for ø10 C12: One-touch fitting for ø12

* Dotted line: Bracket mounting type (-F)

How to Order Manifold



Dimensions

Plug lead unit manifold (VV2Q22-))









Formulas $L_1 = (n - 1) \times 29 + 49$
$L_2 = L_1 - 10$
L3 = L4 - 10.5
L5 = L1 - 11.2

n: Station (Max. 20)

																					100/1. 20)
L	=	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
	Li	49	78	107	136	165	194	223	252	281	310	339	368	397	426	455	484	513	542	571	600
	L2	39	68	97	126	155	184	213	242	271	300	329	358	387	416	445	474	503	532	561	590
	L3	75	100	137.5	162.5	187.5	212.5	250	275	300	337.5	362.5	387.5	425	450	475	500	537.5	562.5	587.5	625
	L4	85.5	110.5	148	173	198	223	260.5	285.5	310.5	348	373	398	435.5	460.5	485.5	510.5	548	573	598	635.5
	L5	37.8	66.8	95.8	124.8	153.8	182.8	211.8	240.8	269.8	298.8	327.8	356.8	385.8	414.8	443.8	472.8	501.8	530.8	559.8	588.8

* Dotted line: DIN rail mounting (-D)

Dimensions



Dimensions

Plug lead unit manifold (VV2Q32-)







Formulas L1 = (n - 1) x 37 + 56
$L_2 = L_1 - 10$
L3 = L4 - 10.5
L5 = L1 - 11.2

Dimensions																		n: St	ation (N	/lax. 20)
L	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L1	56	93	130	167	204	241	278	315	352	389	426	463	500	537	574	611	648	685	722	759
L2	46	83	120	157	194	231	268	305	342	379	416	453	490	527	564	601	638	675	712	749
L3	75	112.5	150	187.5	225	261.5	300	337.5	375	412.5	450	487.5	525	562.5	587.5	625	662.5	700	737.5	775
L4	85.5	123	160.5	198	235.5	273	310.5	348	385.5	423	460.5	498	535.5	573	598	635.5	673	710.5	748	785.5
L5	44.8	81.8	118.8	155.8	192.8	229.8	266.8	303.8	340.8	377.8	414.8	451.8	488.8	525.8	562.8	599.8	636.8	673.8	710.8	747.8

Single Unit Option

Bracket assembly (with 2 mounting screws)

For fixing this solenoid valve.



Туре	Bracket assembly	(Mounting screws, 2 pcs.)
VQ20 Grommet in-line type	AXT835-13A	M3 x 45
VQ20 Grommet L type, DIN terminal type	AXT835-13A-2	M3 x 40
VQ20 DIN terminal L type	AXT835-13A-3	M3 x 35
VQ30	AXT837-13A	M4 x 45

Manifold Option

DIN rail AXT100-DR-□

 Suffix the number from DIN rail dimensions table below. Refer to the dimension drawing for each manifold for L dimension.

Each manifold can be mounted on a DIN rail. Order with the option symbol "-D" to specify DIN rail mounting type.

The DIN rail is approximately 30 mm longer than the length of manifold.



L dimension

- 10	20	301	100	,																
Stations	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
No.	6	8	11	13	15	17	20	22	24	27	29	31	34	36	38	40	43	45	47	50
L	85.5	110.5	148	173	198	223	260.5	285.5	310.5	348	373	398	435.5	460.5	485.5	510.5	548	573	598	635.5

VQ30 series

Stations	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
No.	6	9	12	15	18	21	24	27	30	33	36	39	42	45	47	50	53	56	59	62
L	85.5	123	160.5	198	235.5	273	310.5	348	385.5	423	460.5	498	535.5	573	598	635.5	673	710.5	748	785.5

DIN rail mounting bracket VVQZ100-DB-5

This bracket is used for mounting the manifold on the DIN rail. DIN rail mounting bracket is attached on the manifold.

1 set of DIN rail mounting brackets for 1 manifold includes 2 brackets.







Blanking plate assembly (with O-ring and 2 mounting screws)

Mount a blank plate on valve manifold when a valve is disassembled for maintenance purposes, or when spare valve unit is supposed to be mounted in the future.



Series	Material	Blanking plate assembly	(O-ring)	(Mounting screws, 2 pcs.)
VQ20	HNBR	AXT835-35A	OR-1679-100-H	M3 x 6
VQ20	FKM	AXT835-35A-F	OR-1679-100-F	M3 x 6
VQ30	HNBR	AXT837-35A	OR-2400-150-H	M4 x 6
VQ30	FKM	AXT837-35A-F	OR-2400-150-F	M4 x 6







VQ20/30 Series Specific Product Precautions 1

Be sure to read this before handling the products.

Refer to back page 50 for Safety Instructions and pages 17 to 19 for 2 Port Solenoid Valve for Fluid Control Precautions.

Selection

▲Warning

1. Air quality

This product is for dry air. Drain, oil, etc. in the air may result in faulty operation. Use clean (dry) air.

2. Pressure differential

If a restrictor (nozzle, etc.) is mounted on the outlet side, the outlet side pressure differential at the inlet side is smaller. Be sure the pressure differential when ON does not drop below 0.01 MPa.

Manual Override

Warning

Manual override is used to switch the main valve without inputting an electrical signal for the valve. (DIN terminal only.)

Slotted locking type (tool required)



Push the manual override button with a small flat head screwdriver until it stops. Turn it in the counterclockwise direction at 90° to lock the manual. Turn it right to release.



Connection and Electrical Circuit

A Caution



With DC voltage power-saving circuit (with polarity)



DC (with power-saving circuit) specifications is designed to reduce the power consumption at holding to achieve powersaving by circuit shown above. Refer to below power wave form.

Connection and Electrical Circuit

▲ Caution

Power wave form of power-saving type (Rated voltage at 24 VDC)



AC circuit

Lead wire color Blue (100 VAC) Red (200 VAC) Gray (Other AC)

Blue (100 VAC) Red (200 VAC) Gray (Other AC)



Valve Mounting

▲ Caution

When mounting the valve, secure with brackets. When mounting it directly, tighten the mounting screws with the appropriate torque (0.7 to 0.8 N-m).

Mounting screw

0.7 to 0.8 N·m

Tightening torque



When Energizing Continuously for Long Period of Time

▲ Caution

When energizing continuously, choose the option of an energysaving circuit specifications. High speed response type (with no energy-saving circuit) cannot be energized continuously.



VQ20/30 Series Specific Product Precautions 2

Be sure to read this before handling the products.

Refer to back page 50 for Safety Instructions and pages 17 to 19 for 2 Port Solenoid Valve for Fluid Control Precautions.

How to Wire DIN Terminal

▲ Caution

ISO#: Based on DIN 43650C (Pin gap 8 mm) Connection

- 1. Loosen the tightening screw and pull the connector off of the solenoid valve.
- 2. After removing the tightening screw, divide the terminal block and housing by prying open the slot area of the lower part of the terminal block open with a screwdriver.
- **3.** Loosen the terminal screws of the block and insert stripped lead wires in accordance with the wiring diagram. Secure each wire by re-tightening the terminal screw (In the case of terminal 1: (+), 2: (-) DC)
- 4. Tighten the ground nut to secure the cable wire.

Change of electrical entry

Wire entry can be changed by mounting the housing in either direction (four directions at every 90°) after dividing the terminal block and the housing.

* For the indicator lighted type, be careful not to damage the light with the lead wire of the cable.

Precautions

Insert a connector straight or pull it out straight, using caution it does not be tilted.

Applicable cable

Cord O.D.: ø3.5 to ø7

(Reference) 0.5 mm² 2-core and 3-core wire equivalent to JIS C 3306.



DIN (EN175301-803) Terminal

This DIN terminal corresponds to the Form C DIN connector with an 8 mm terminal pitch, which complies with EN175301-803B.



DIN Terminal Part No. (Based on DIN)

ithout indicator light	SY100-82-4									
With Indicator Light										
Rated voltage	Voltage symbol	Part no.								
24 VDC	24 V	SY100-82-3-05								
12 VDC	12 V	SY100-82-3-06								
100 VAC	100 V	SY100-82-2-01								
200 VAC	200 V	SY100-82-2-02								
110 VAC	110 V	SY100-82-2-03								
220 VAC	220 V	SY100-82-2-04								

How to Wire DIN Terminal

DIN Terminal Circuit with Indicator Light



Manifold

How to Mount/Remove from DIN Rail

Caution

Removing procedure

- 1. Loosen the clamp screw on the " (A) " side of both ends of the manifold.
- Lift the " (A) " side of the manifold off the DIN rail and slide it in the direction of the arrow.

Mounting procedure

- Hook the mounting hook on the "

 B " side of the manifold base to the DIN rail.
- Press down side " (A) " and mount the end plate on the DIN rail. Tighten the clamp screw on side " (B) " of the end plate.

(Tightening torque: 0.3 to 0.4 N·m).

Valve Mounting

▲ Caution

After confirming the gasket is correctly placed under the valve, tighten the mounting screws with the appropriate torque (0.7 to 0.8 N·m).



Manifold mounting screw



